

DLP™ PROJECTOR

MODEL EIP-2500

EIP-200





OWNER'S MANUAL

EIKI INDUSTRIAL CO., LTD.

IMPORTANT

- For your assistance in reporting the loss or theft of your Projector, please record the Model and Serial Number located on the bottom of the projector and retain this information.
- Before recycling the packaging, please ensure that you have checked the contents of the carton thoroughly against the list of "Supplied accessories" on page 10.

RЛ	od	ام	NI	\sim	•
IVI	u	CI	1.4	v.	

Serial No.:

SPECIAL NOTE FOR USERS IN THE U.K.

The mains lead of this product is fitted with a non-rewireable (moulded) plug incorporating a 10A fuse. Should the fuse need to be replaced, a BSI or ASTA approved BS 1362 fuse marked \heartsuit or a and of the same rating as above, which is also indicated on the pin face of the plug, must be used.

Always refit the fuse cover after replacing the fuse. Never use the plug without the fuse cover fitted.

In the unlikely event of the socket outlet in your home not being compatible with the plug supplied, cut off the mains plug and fit an appropriate type.

DANGER:

The fuse from the cut-off plug should be removed and the cut-off plug destroyed immediately and disposed of in a safe manner.

Under no circumstances should the cut-off plug be inserted elsewhere into a 13A socket outlet, as a serious electric shock may occur.

To fit an appropriate plug to the mains lead, follow the instructions below:

WARNING:

THIS APPARATUS MUST BE EARTHED.

IMPORTANT:

The wires in this mains lead are coloured in accordance with the following code:

Green-and-yellow: Earth
Blue: Neutral
Brown: Live

As the colours of the wires in the mains lead of this apparatus may not correspond with the coloured markings identifying the terminals in your plug proceed as follows:

- The wire which is coloured green-and-yellow must be connected to the terminal in the plug which is marked by the letter E or by the safety earth symbol

 → or coloured green or green-and-yellow.
- The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black.
- The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.

IF YOU HAVE ANY DOUBT. CONSULT A QUALIFIED ELECTRICIAN.

This apparatus complies with the requirements of Council Directives 89/336/EEC and 73/23/EEC as amended by Council Directive 93/68/EEC.

Dieses Gerät entspricht den Anforderungen der EG-Richtlinien 89/336/EWG und 73/23/EWG mit Änderung 93/68/EWG.

Ce matériel répond aux exigences contenues dans les directives 89/336/CEE et 73/23/CEE modifiées par la directive 93/68/CEE.

Dit apparaat voldoet aan de eisen van de richtlijnen 89/336/EEG en 73/23/EEG, gewijzigd door 93/68/EEG.

Dette udstyr overholder kravene i direktiv nr. 89/336/EEC og 73/23/EEC med tillæg nr. 93/68/EEC.

Quest' apparecchio è conforme ai requisiti delle direttive 89/336/EEC e 73/23/EEC, come emendata dalla direttiva 93/68/EEC.

Αυτή η συσκευή συμμορφώνεται με τις απαιτήσεις των οδηγιών του Συμβουλίου 89/336/ΕΟΚ και 73/23/ΕΟΚ όπως τροποποιήθηκαν από την οδηγία του Συμβουλίου 93/68/ΕΟΚ.

Este equipamento obedece às exigências das directivas 89/336/CEE e 73/23/CEE, na sua versão corrigida pela directiva 93/68/CEE.

Este aparato satisface las exigencias de las Directivas 89/336/CEE y 73/23/CEE, modificadas por medio de la 93/68/CEE.

Denna utrustning uppfyller kraven enligt riktlinjerna 89/336/EEC och 73/23/EEC så som kompletteras av 93/68/EEC.

Dette produktet oppfyller betingelsene i direktivene 89/336/EEC og 73/23/EEC i endringen 93/68/EEC.

Tämä laite täyttää direktiivien 89/336/EEC ja 73/23/EEC vaatimukset, joita on muutettu direktiivillä 93/68/EEC.

Bu cihaz Konsey Direktifi 93/68/EEC tarafından düzeltilen 89/336/EEC ve 73/23/EEC Konsey Direktiflerinin gerekliliklerine uygundur.

Tento přístroj je v souladu s požadavky směrnic rady 89/336/EEC a 73/23/EEC, tak jak byly upraveny směrnicí rady 93/68/EEC.

See seade on vastavuses Nõukogu Direktiivis nr 89/336/EEC ja 73/23/EEC esitatud nõuetega, vastavalt Nõukogu Direktiivis nr 93/68/EEC esitatud parandustele

Ez a készülék megfelel a Tanács által kiadott, 89/336/EGK és 73/23/EGK Irányelveknek és az utóbbit módosító 93/68/EGK Irányelvnek

Ši ierice atbilst tehniskam prasibam pec 89/336/EEC un 73/23/EEC direktivam papildinats ar direktivu 93/68/EEC.

Šis prietaisas atitinka ES Tarybos direktyvu 89/336/EEC ir 73/23/EEC patikslintos direktyvos 93/68/EEC reikalavimus.

To urządzenie spełnia wymagania dyrektyw 89/336/EEC i 73/23/EEC wraz z poprawkami dyrektywy 93/68/EEC.

Tento prístroj je v súlade s požiadavkami smerníc rady 89/336/EEC a 73/23/EEC tak ako boli upravené smernicou rady 93/68/EEC.

Ta aparat je v skladu z zahtevami Direktiv Sveta 89/336/EEC in 73/23/EEC kot je navedeno v dopolnilu k Direktivi Sveta 93/68/EEC.

The supplied CD-ROM contains operation instructions in English, German, French, Spanish, Italian and Portuguese. Carefully read through the operation instructions before operating the projector.

Die mitgelieferte CD-ROM enthält Bedienungsanleitungen in Englisch, Deutsch, Französisch, Spanisch, Italienisch und Portugiesisch. Bitte lesen Sie die Bedienungsanleitung vor der Verwendung des Projektors sorgfältig durch.

Le CD-ROM fourni contient les instructions de fonctionnement en anglais, allemand, français, espagnol, italien et portugais. Veuillez lire attentivement ces instructions avant de faire fonctionner le projecteur.

El CD-ROM suministrado contiene instrucciones de operación en inglés, alemán, francés, español, italiano y portugués. Lea cuidadosamente las instrucciones de operación antes de utilizar el proyector.

Il CD-ROM in dotazione contiene istruzioni per l'uso in inglese, tedesco, francese, spagnolo, italiano e portoghese. Leggere attentamente le istruzioni per l'uso prima di usare il proiettore.

O CD-ROM fornecido contém instruções de operação em Inglês, Alemão, Francês, Espanhol, Italiano e Português. Leia cuidadosamente todas as instruções de operação antes de operar o projetor.

Introduction

ENGLISH

1. WARRANTY

This is to assure that you immediately receive the full benefit of the parts, service and labor warranty applicable to your purchase.

2. CONSUMER PRODUCT SAFETY ACT

To ensure that you will promptly receive any safety notification of inspection. modification, or recall that EIKI may be required to give under the 1972 Consumer Product Safety Act, PLEASE READ CAREFULLY THE IMPORTANT "LIMITED WARRANTY" CLAUSE. U.S.A. ONLY

WARNING: High brightness light source. Do not stare into the beam of light, or view directly. Be especially careful that children do not stare directly into the beam of light.

WARNING: To reduce the risk of fire or electric shock, do not expose this product to rain or moisture.

See bottom of projector.



CAUTION RISK OF ELECTRIC SHOCK. DO NOT REMOVE SCREWS **EXCEPT SPECIFIED USER** SERVICE SCREW.

PERSONNEL



CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK. DO NOT REMOVE COVER. NO USER-SERVICEABLE PARTS EXCEPT LAMP UNIT. REFER SERVICING TO QUALIFIED SERVICE



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk or electric shock to persons.



The exclamation point within a triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

WARNING: FCC Regulations state that any unauthorized changes or modifications to this equipment not expressly approved by the manufacturer could void the user's authority to operate this equipment. U.S.A. ONLY

WARNING:

The cooling fan in this projector continues to run for about 90 seconds after the projector enters standby mode. During normal operation, when putting the projector into standby mode always use the STANDBY-ON button on the projector or the STANDBY button on the remote control. Ensure the cooling fan has stopped before disconnecting the power cord.

DURING NORMAL OPERATION, NEVER TURN THE PROJECTOR OFF BY DISCONNECTING THE POWER CORD. FAILURE TO OBSERVE THIS WILL RESULT IN PREMATURE LAMP FAILURE.

INFORMATION

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the owner's manual, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

U.S.A. ONLY

Declaration of conformity

EIKI PROJECTOR, MODEL EIP-2500/EIP-200

This device complies with Part 15 of the FCC rules. Operation is subject to the following conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Responsible Party:

EIKI INTERNATIONAL, INC.

30251 Esperanza Rancho Santa Margarita, CA 92688-2132

TFI: 800-242-3454

U.S.A. ONLY

PRODUCT DISPOSAL

This projector utilizes tin-lead solder, and a pressurized lamp containing a small amount of mercury. Disposal of these materials may be regulated due to environmental considerations. For disposal or recycling information, please contact your local authorities or, if you are located in the United States of America, the Electronic Industries Alliance; www.eiae.org.

Caution Concerning Lamp Replacement


See "Replacing the Lamp" on page 50.

This EIKI projector uses a DMD panel. This very sophisticated panel contains 786,432 (EIP-2500) / 480,000 (EIP-200) pixels (micromirrors). As with any high technology electronic equipment such as large screen TVs, video systems and video cameras, there are certain acceptable tolerances that the equipment must conform to.

This unit has some inactive pixels within acceptable tolerances which may result in inactive dots on the picture screen. This will not affect the picture quality or the life expectancy of the unit.

How to Read this Owner's Manual

- The specifications are slightly different, depending on the model. However, you can connect and operate all models in the same manner.
- In this owner's manual, the illustration and the screen display are simplified for explanation, and may differ slightly from the actual display.



InfoIndicates safeguards for using the projector.

Note......Indicates additional information for setting up and operating the projector.

For Future Reference

Maintenance Troubleshooting

Index

→ P. 47

→ PP. 59 and 60

→ P. 63

Contents

Preparing

Int	ro	٨	 cti	_	n

How to Read this Owner's Manual 3 Contents
Manuals9Accessories10Part Names and Functions11Inserting the Batteries14Usable Range15
Quick Start
Quick Start

Setup

Setting up the Projector	. 18
Setting up the Projector	
Standard Setup (Front Projection)	18
Ceiling-mount Setup	18
Projection (PRJ) Mode	19
Screen Size and Projection Distance	20

Connections

Connections	21
Samples of Cables for Connection	22
Connecting to a Computer	23
Connecting to Video Equipment	24
Connecting to a Monitor with RGB In	put
Terminal	25
Controlling the Projector by	
a Computer	26
Connecting the Power Cord	26

Using

Basic Operation

Turning the Projector On/Off	27
Turning the Projector on	. 27
Turning the Power off (Putting the	
Projector into Standby Mode)	. 27
Image Projection	28
About the Setup Guide	
Adjusting the Projected Image	
Switching the Input Mode	. 30
Adjusting the Volume	
Displaying the Black Screen and Turn	ing
off the Sound Temporarily	. 30
Correcting Trapezoidal Distortion	. 31
Resize Mode	. 32

Useful Features

Operating with the Remote Control	. 34
Displaying and Setting	
the Break Timer	34
Auto Sync (Auto Sync Adjustment)	
Freezing a Moving Image	34
Selecting the Picture Mode	34
Menu Items	. 35
Using the Menu Screen	. 37
Menu Selections (Adjustments)	37
Picture Adjustment ("Picture" menu)	. 39
Selecting the Picture Mode	39
Adjusting the Image	40
Adjusting the Color Temperature	401
Troil projector mandaneon Entre man	cretit.

Progressive	40
Lamp Setting	40
Adjusting the Projected Image	
("SCR - ADJ" menu)	41
Setting the Resize Mode	
Adjusting the Image Position	
Keystone Correction	
Setting On-screen Display	
Selecting the Background Image	
Selecting the Setup Guide	42
Reversing/Inverting Projected	
Images	42
Selecting the On-screen Display	
Language	42
Adjusting the Projector Function	
("PRJ - ADJ" menu)	43
Auto Search Function	
Auto Sync (Auto Sync Adjustment)	
Auto Power Off Function	43
Setting the Confirmation Sound	
(System Sound)	
Speaker Setting	43
Selecting the Transmission Speed	
(RS-232C)	
Fan Mode Setting	
Checking the Lamp Life Status	
System Lock Function	44
Locking the Operation Buttons on the	4.5
Projector (Keylock Function)	45
Troubleshooting with "Help" menu	
Utilizing "Help" menu functions	46

Reference

Appendix

Maintenance	
Regarding the Lamp	
Lamp	
Caution Concerning the Lamp	50
Replacing the Lamp	50
Removing and Installing	
the Lamp Unit	51
Resetting the Lamp Timer	52

Connecting Pin Assignments	53
RS-232C Specifications and Comman	d
Settings	54
Computer Compatibility Chart	
Troubleshooting	59
Specifications	61
Dimensions	62
ndex	63

IMPORTANT SAFEGUARDS

CAUTION: Please read all of these instructions before you operate this product and save these instructions for later use.

Electrical energy can perform many useful functions. This product has been engineered and manufactured to assure your personal safety. BUT IMPROPER USE CAN RESULT IN POTENTIAL ELECTRICAL SHOCK OR FIRE HAZARDS. In order not to defeat the safeguards incorporated in this product, observe the following basic rules for its installation, use and servicing.

1. Read Instructions

All the safety and operating instructions should be read before the product is operated.

2. Retain Instructions

The safety and operating instructions should be retained for future reference.

3. Heed Warnings

All warnings on the product and in the operating instructions should be adhered to.

4. Follow Instructions

All operating and use instructions should be followed.

5. Cleaning

Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.

6. Attachments

Do not use attachments not recommended by the product manufacturer as they may cause hazards.

7. Water and Moisture

Do not use this product near water-for example, near a bath tub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool; and the like.

8. Accessories

Do not place this product on an unstable cart, stand, tripod, bracket, or table. The product may fall, causing serious injury to a child or adult, and serious damage to the product. Use only with a cart, stand, tripod, bracket, or table recommended by the manufacturer, or sold with the product. Any mounting of the product should follow the manufacturer's instructions, and should use a mounting accessory recommended by the manufacturer.

9. Transportation

A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart combination to overturn.



10. Ventilation

Slots and openings in the cabinet are provided for ventilation to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built-in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.

11. Power Sources

This product should be operated only from the type of power source indicated on the marking label. If you are not sure of the type of power supply to your home, consult your product dealer or local power company. For products intended to operate from battery power, or other sources, refer to the operating instructions.

12. Grounding or Polarization

This product is provided with one of the following types of plugs. If the plug should fail to fit into the power outlet, please contact your electrician. Do not defeat the safety purpose of the plug.

Two-wire type (mains) plug.

b. Three-wire grounding type (mains) plug with a grounding terminal.

This plug will only fit into a grounding type power outlet.

13. Power-Cord Protection

Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.

14. Lightning

For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the cable system. This will prevent damage to the product due to lightning and power-line surges.

15. Overloading

Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.

16. Object and Liquid Entry

Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.

17. Servicing

Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.

18. Damage Requiring Service

Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions:

- a. When the power-supply cord or plug is damaged.
- b. If liquid has been spilled, or objects have fallen into the product.
- c. If the product has been exposed to rain or water.
- d. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions, as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.
- e. If the product has been dropped or damaged in any way.
- f. When the product exhibits a distinct change in performance, this indicates a need for service

19. Replacement Parts

When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.

20. Safety Check

Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.

21. Wall or Ceiling Mounting

This product should be mounted to a wall or ceiling only as recommended by the manufacturer.

22. Heat


This product should be situated away from heat sources such as radiators, heat registers, stoves, or other products (including amplifiers) that produce heat.

- DLP™ (Digital Light Processing) and DMD™ (Digital Micromirror Device) are trademarks of Texas Instruments, Inc.
- Microsoft[®] and Windows[®] are registered trademarks of Microsoft Corporation in the United States and/or other countries.
- PC/AT is a registered trademark of International Business Machines Corporation in the United States.
- Adobe® Reader® is a trademark of Adobe Systems Incorporated.
- Macintosh® is a registered trademark of Apple Computer, Inc. in the United States and/or other countries.
- All other company or product names are trademarks or registered trademarks of their respective companies.
- Some IC chips in this product include confidential and/or trade secret property belonging to Texas Instruments. Therefore you may not copy, modify, adapt, translate, distribute, reverse engineer, reverse assemble or discompile the contents thereof.

Observe the following safeguards when setting up your projector.

Caution concerning the lamp unit

■ Potential hazard of glass particles if lamp ruptures. In case of lamp rupture, contact your nearest EIKI Authorized Dealer or Service Center for replacement.





Caution concerning the setup of the projector

For minimal servicing and to maintain high image quality, EIKI recommends that this projector be installed in an area free from humidity, dust and cigarette smoke. When the projector is subjected to these environments, the vents and lens must be cleaned more often. As long as the projector is regularly cleaned, use in these environments will not reduce the overall operation life of the unit. Internal cleaning should only be performed by an EIKI Authorized Dealer or Service Center.


Do not set up the projector in places exposed to direct sunlight or bright light.

Position the screen so that it is not in direct sunlight or room light. Light falling directly on the screen washes out the colors, making viewing difficult. Close the curtains and dim the lights when setting up the screen in a sunny or bright room.

Caution regarding placing of the projector

Place the projector on a level site within the adjustment range (8 degrees) of the adjustment foot.





When using the projector in high-altitude areas such as mountains (at altitudes of approximately 1,500 meters (4,900 feet) or more)

When you use the projector in high-altitude areas with thin air, set "Fan Mode" to "High". Neglecting this can affect the longevity of the optical system.

Warning about placing the projector in a high position

When placing the projector in a high position, ensure that it is secured carefully to avoid personal injury caused by the projector falling down.

Do not subject the projector to hard impact and/or vibration.

■ Protect the lens so as not to hit or damage the surface of the lens.

Rest your eyes occasionally.

 Continuously watching the screen for long hours will cause eye strain. Be sure to occasionally rest your eyes.

Avoid locations with extremes of temperature.

- The operating temperature of the projector is from 41°F to 95°F (+5°C to +35°C).
- The storage temperature of the projector is from -4°F to 140°F (-20°C to +60°C).

Do not block the exhaust and intake vents.

- Allow at least 11 ¹³/₁₆ inches (30 cm) of space between the exhaust vent and the nearest wall or obstruction.
- Be sure that the intake vent and the exhaust vent are not obstructed.
- If the cooling fan becomes obstructed, a protection circuit will automatically put the projector into standby mode to prevent overheat damage. This does not indicate a malfunction. (See pages 48 and 49.) Remove the projector power cord from the wall outlet and wait at least 10 minutes. Place the projector where the intake and exhaust vents are not blocked, plug the power cord back in and turn on the projector. This will return the projector to the normal operating condition.

When turning off the projector, the cooling fan runs to decrease the internal temperature for a while. Unplug the power cord after the cooling fan stops. The period the cooling fan runs will vary, depending on the circumstances and the internal temperature.

Caution regarding usage of the projector

- When using the projector, be sure not to subject it to hard impact and/or vibration, as this can result in damage. Take extra care with the lens. Before moving the projector, be sure to unplug the power cord from the wall outlet, and disconnect any other cables connected to it.
- Do not carry the projector by holding the lens.
- When storing the projector, re-attach the lens cap. (See page 11).
- Do not expose the projector to direct sunlight or place next to heat sources. Doing so may affect the cabinet color or cause deformation of the plastic cover.

Other connected equipment

- When connecting a computer or other audiovisual equipment to the projector, make the connections AFTER unplugging the power cord of the projector from the AC outlet and turning off the equipment to be connected.
- Please read the owner's manuals of the projector and the equipment to be connected for instructions on how to make the connections.

Using the projector in other countries

■ The power supply voltage and the shape of the plug may vary depending on the region or country you are using the projector in. When using the projector overseas, be sure to use an appropriate power cord for the country you are in.

Temperature monitor function



■ If the projector starts to overheat due to setup problems or blockage of the air vents, "

" TEMP." will illuminate in the lower left corner of the picture. If the temperature continues to rise, the lamp will turn off, the temperature warning indicator on the projector will blink, and after a 90-second cooling-off period the projector will enter standby mode. Refer to "Maintenance Indicators" on page 48 for details.

Info

- The cooling fan regulates the internal temperature, and its performance is automatically controlled. The sound of the fan may change during projector operation due to changes in the fan speed. This does not indicate malfunction.
- Do not unplug the power cord during projection or cooling fan operation. This can cause damage due to rise in internal temperature, as the cooling fan also stops.

How to Access the PDF Owner's Manuals

PDF owner's manuals in several languages are included in the CD-ROM, so that you can work with the projector, even if you do not have this manual. To utilize these manuals, you need to install Adobe® Reader® on your computer (Windows® or Macintosh®).

Please download Adobe® Reader® from the Internet (http://www.adobe.com).

Accessing the PDF Manuals for Windows® (For Macintosh®, skip step ②).


- (1) Insert the CD-ROM in the CD-ROM drive.
- Double click the "My Computer" icon.
- (3) Double click the "CD-ROM" drive.
- Double click the language (name of the folder) that you want to view.
- ⑤ Double click the "2_25_" pdf file to access the projector manuals.



• If the desired pdf file cannot be opened by double clicking the mouse, start Adobe® Reader® first, then specify the desired file using the "File", "Open" menu.

Accessories

Supplied accessories




Optional accessory

■ Lamp unit	AH-66271 (for EIP-2500)
· ·	AH-15001 (for EIP-200)

Part Names and Functions

Numbers in refer to the main pages in this owner's manual where the topic is explained.


Projector



Part Names and Functions (Continued)


Numbers in refer to the main pages in this owner's manual where the topic is explained.

Rear View



Using the Kensington Lock


 This projector has a Kensington Security Standard connector for use with a Kensington MicroSaver Security System. Refer to the information that came with the system for instructions on how to use it to secure the projector. Numbers in refer to the main pages in this owner's manual where the topic is explained.



Part Names and Functions (Continued)

Inserting the Batteries

1 Press the ▲ mark on the cover and slide it in the direction of the arrow.




2 Insert the batteries.

• Insert the batteries making sure the polarities correctly match the \bigoplus and \bigoplus marks inside the battery compartment.



Attach the cover and slide it until it clicks into place.



Incorrect use of the batteries may cause them to leak or explode. Please follow the precautions below.



Caution

- Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- Insert the batteries making sure the polarities correctly match the

 and

 marks inside the battery compartment.
- Batteries of different types have different properties, therefore do not mix batteries of different types.
- Do not mix new and old batteries.
- This may shorten the life of new batteries or may cause old batteries to leak.
- Remove the batteries from the remote control once they have run out, as leaving them in can cause them
 to leak.
 - Battery fluid from leaked batteries is harmful to skin, therefore ensure that you first wipe them and then remove them using a cloth.
- The batteries included with this projector may run down in a short period, depending on how they are kept. Be sure to replace them as soon as possible with new batteries.
- Remove the batteries from the remote control if you will not be using the remote control for a long time.
- Comply with the rules (ordinance) of each local government when disposing of worn-out batteries.

Usable Range


The remote control can be used to control the projector within the ranges shown in the illustration.



• The signal from the remote control can be reflected off a screen for easy operation. However, the effective distance of the signal may differ depending on the screen material.

When using the remote control

- Ensure that you do not drop, expose to moisture or high temperature.
- The remote control may malfunction under a fluorescent lamp. In this case, move the projector away from the fluorescent lamp.




Quick Start

This section shows the basic operation (projector connecting with the computer). For details, see the page described below for each step.


Setup and Projection

In this section, connection of the projector and the computer is explained using one example.





2. Connect the projector to the computer and plug the power cord into the AC socket of the projector



When connecting equipment other than the computer, see pages 24 and 25.

➡PP. 21-26

3. Remove the lens cap and turn the projector on



On the projector

ഠി

On the remote control





₽ 27

4. Adjust the projected image with the Setup Guide

- 1 After the projector turns on, the Setup Guide appears. (When "Setup Guide" is set to "On". → page 42)
- **2** Follow the steps in the Setup Guide and adjust the focus, screen size, and height (angle).
- 3 After adjusting the focus, height (angle) and screen size, press □ENTER to finish the Setup Guide.

→ P. 28

5. Turn the computer on

6. Select the INPUT mode

Select the "INPUT 1" using the INPUT button on the projector or INPUT 1 on the remote control.

On the On the remote On-screen display (RGB)







- When pressing the INPUT button on the projector, input mode switches in the following order: →INPUT1↔INPUT3↔INPUT3↔INPUT4←
- When using the remote control, press the INPUT 1/INPUT 2/INPUT 3/INPUT 4 button to switch the INPUT mode.

7. Correct trapezoidal distortion

Correcting trapezoidal distortion using the Keystone Correction. (Keystone Correction functions automatically on EIP-2500.)





8. Turn the Power off

Press the STANDBY-ON button on the projector or the STANDBY button on the remote control, and then press the button again while the confirmation message is displayed, to put the projector into standby mode.

On the projector control

On-screen Display

Enter STANDBY mode?

Yes: Press Again

No: Please Wait

• Unplug the power cord from the AC outlet after the cooling fan stops.

→ P. 27

Setting up the Projector

Setting up the Projector

For optimal image quality, position the projector perpendicular to the screen with the projector's feet flat and level. Doing so will eliminate the need for Keystone correction and provide the best image quality. (See page 31.)


Standard Setup (Front Projection)

■ Place the projector at the required distance from the screen according to the desired picture size. (See page 20.)



Example of standard setup

Side View






• Refer to page 20 for additional information concerning "Screen Size and Projection Distance".

Ceiling-mount Setup


- It is recommended that you use the optional EIKI ceiling-mount bracket for this installation. Before mounting the projector, contact your nearest EIKI Authorized Dealer or Service Center to obtain the recommended ceilingmount bracket (sold separately).
- Invert the image by setting "Ceiling + Front" in "PRJ Mode". See page 42 for use of this function.




Projection (PRJ) Mode

The projector can use any of the 4 projection modes, shown in the diagram below. Select the mode most appropriate for the projection setting in use. (You can set the PRJ mode in "SCR-ADJ" menu. See page 42.)

■ Table mounted, front projection




Ceiling mounted, front projection




Menu item → "Front"

■ Table mounted, rear projection (with a translucent screen)



Menu item → "Ceiling + Front"

■ Ceiling mounted, rear projection (with a translucent screen)




Menu item → "Ceiling + Rear"

Menu item → "Rear"

Indication of the Projection Image Size and Projection Distance

Example: NORMAL Mode (4:3)



Setting up the Projector (Continued)

Screen Size and Projection Distance

NORMAL Mode (4:3)

Pic	Picture (Screen) size Projection distance [L]		Distance from the lens center		
Diag. [χ]	Width	Height	Minimum [L1]	Maximum [L2]	to the bottom of the image [H]
300" (762 cm)	610 cm (240")	457 cm (180")	10.4 m (34' 3")	12.1 m (39' 8")	-48 cm (-19 ⁵ / ₆₄ ")
270" (686 cm)	549 cm (216")	411 cm (162")	9.4 m (30′ 10″)	10.9 m (35' 8")	-44 cm (-17 ¹¹ / ₆₄ ")
250" (635 cm)	508 cm (200")	381 cm (150")	8.7 m (28' 7")	10.1 m (33' 1")	$-40 \text{ cm} (-15 {}^{57}\!/_{64}")$
200" (508 cm)	406 cm (160")	305 cm (120")	7.0 m (22' 10")	8.1 m (26' 5")	-32 cm (-12 ²³ / ₃₂ ")
150" (381 cm)	305 cm (120")	229 cm (90")	5.2 m (17' 2")	6.0 m (19' 10")	$-24 \text{ cm } (-9^{17}/_{32}")$
100" (254 cm)	203 cm (80")	152 cm (60")	3.5 m (11' 5")	4.0 m (13' 3")	- 16 cm (-6 ²³ / ₆₄ ")
84" (213 cm)	171 cm (67")	128 cm (50")	2.9 m (9' 7")	3.4 m (11' 1")	- 14 cm (-5 ¹¹ / ₃₂ ")
72" (183 cm)	146 cm (58")	110 cm (43")	2.5 m (8' 3")	2.9 m (9' 6")	- 12 cm (-4 ³⁷ / ₆₄ ")
60" (152 cm)	122 cm (48")	91 cm (36")	2.1 m (6′ 10″)	2.4 m (7' 11")	- 10 cm (-3 ¹³ / ₁₆ ")
40" (102 cm)	81 cm (32")	61 cm (24")	1.4 m (4' 7")	1.6 m (5' 3")	-6 cm (-2 ³⁵ / ₆₄ ")

- χ: Picture size (diag.) (in/cm)
- L: Projection distance (m/ft)
- L1: Minimum projection distance (m/ft)
- L2: Maximum projection distance (m/ft)
- H: Distance from the lens center to the bottom of the image (cm/in)

The formula for picture size and projection distance [m/cm] [Feet/inches]

L1 (m) = 0.03482χ L2 (m) = 0.04029χ H (cm) = -0.16151χ L1 (ft) = $0.03482\chi / 0.3048$ L2 (ft) = $0.04029\chi / 0.3048$ H (in) = $-0.16151\chi / 2.54$

STRETCH Mode (16:9)

Picture (Screen) size			Projection distance [L]		Distance from the lens center to	Adjustable range of
Diag. [χ]	Width	Height	Minimum [L1]	Maximum [L2]	the bottom of the image [H]	image position [S]
250" (635 cm)	553 cm (218")	311 cm (123")	9.5 m (31' 1")	11.0 m (36′ 0″)	$-96 \text{ cm } (-37 {}^{3}/{4}'')$	±52 cm ($\pm20^{27}\!/_{64}{}'')$
225" (572 cm)	498 cm (196")	280 cm (110")	8.5 m (28' 0")	9.9 m (32′ 5″)	$-86 \text{ cm } (-33^{31}/_{32}")$	±47 cm (±18 $^{25}/_{64}{''})$
200" (508 cm)	443 cm (174")	249 cm (98")	7.6 m (24' 11")	8.8 m (28' 10")	$-77 \text{ cm } (-30 ^{13}/_{64}")$	±42 cm (±16 $^{11}/_{32}{''})$
150" (381 cm)	332 cm (131")	187 cm (74")	5.7 m (18' 8")	6.6 m (21' 7")	$-58 \text{ cm } (-22 ^{41}/_{64}")$	±31 cm (±12 $^{1}\!/_{4}")$
133" (338 cm)	294 cm (116")	166 cm (65")	5.0 m (16' 7")	5.8 m (19' 2")	$-51 \text{ cm } (-20 ^{5}/_{64}")$	±28 cm ($\pm10^{7}\text{/s"})$
106" (269 cm)	235 cm (92")	132 cm (52")	4.0 m (13' 2")	4.7 m (15′ 3″)	-41 cm (-16")	±22 cm ($\pm8^{21}/_{32}{}'')$
100" (254 cm)	221 cm (87")	125 cm (49")	3.8 m (12' 5")	4.4 m (14' 5")	-38 cm (-15 ³ / ₃₂ ")	±21 cm (±8 $^{11}/_{64}"$)
92" (234 cm)	204 cm (80")	115 cm (45")	3.5 m (11' 5")	4.0 m (13' 3")	$-35 \text{ cm } (-13^{57}/_{64}")$	±19 cm (±7 $^{33}/_{64}")$
84" (213 cm)	186 cm (73")	105 cm (41")	3.2 m (10′ 5″)	3.7 m (12′ 1″)	$-32 \text{ cm } (-12 {}^{11}/_{16}")$	±17 cm (±6 $^{55}/_{64}")$
72" (183 cm)	159 cm (63")	90 cm (35")	2.7 m (9' 0")	3.2 m (10′ 4″)	$-28 \text{ cm } (-10^{7}/8")$	±15 cm (±5 $^{57}/_{64}")$
60" (152 cm)	133 cm (52")	75 cm (29")	2.3 m (7' 6")	2.6 m (8' 8")	-23 cm (-9 ¹ / ₁₆ ")	\pm 12 cm (\pm 4 ²⁹ / ₃₂ ")
40" (102 cm)	89 cm (35")	50 cm (20")	1.5 m (5' 0")	1.8 m (5′ 9″)	$-15 \text{ cm } (-6 {}^{3}/_{64}")$	\pm 8 cm (\pm 3 ¹⁷ / ₆₄ ")


- χ: Picture size (diag.) (in/cm)
- L: Projection distance (m/ft)
- L1: Minimum projection distance (m/ft)
- L2: Maximum projection distance (m/ft)
- H: Distance from the lens center to the bottom of the image (cm/in)
- S: Adjustable range of image position (cm/in) See page 41.
- The formula for picture size and projection distance [m/cm] [Feet/inches]
- $H (cm) = -0.3835\chi$ $H (in) = -0.3835\chi / 2.54$ $S (cm) = \pm 0.20754\chi$ $S (in) = \pm 0.20754\chi / 2.54$



- Refer to page 18 concerning "Projection distance (L)" and "Distance from the lens center to the bottom of the image (H)".
- There are some errors in the values in the diagrams above.
- Values with a minus (-) sign indicate the distance from the lens center below the bottom of the image.

Connections

INPUT Terminals and Connectable Main Equipment



terminal.

Samples of Cables for Connection

- For more details of connection and cables, refer to the owner's manual of the connecting equipment.
- You may need other cables or connectors not listed below.


Equipment	Input Signal	Cable	Terminal on the projector
Computer	DOD	RGB cable (supplied)	INPUT1, 2
	RGB video		COMPITERHOLOGOMOSEM COMPITERHOLOGOMOSEM COMPITERHOLOGOMOSEM
	Computer audio	ø3.5 mm stereo audio cable (commercially available)	AUDIO INPUT
Audio-visual equipment	Compo- nent video	3 RCA (Component) to 15-pin D-sub cable (supplied)	INPUT1, 2
•• ••	S-video	S-video cable (commercially available)	INPUT3
		Video cable (commercially available)	INPUT4
	Video		INMUT 4
	Audio	ø3.5 mm minijack to RCA audio cable (commercially available)	AUDIO INPUT or or large 36 March
Camera/ video game		Cables for a camera or a video game/3 RCA (Component) to 15-pin D-sub cable (supplied)	INPUT1, 2
	Compo- nent video	RCA adaptor plug (commercially available)	CONVITTMENT CONV
	S-video	Cables for a camera or a video game	INPUT3
	Video	Cables for a camera or a video game	INPUT4
	Audio	Cables for a camera or a video game/ø3.5 mm minijack to RCA audio cable (commercially available) RCA adaptor plug (commercially available) or connect directly to	AUDIO INPUT or interpretation of interpretatio
oaded From project	or-manual.c	AUDIO (INPUT 3, 4).	

Down baded From projector-manual.com EIKI Manua

Connecting to a Computer

Before connecting, ensure that the power cord of the projector is unplugged from the AC outlet and turn off the devices to be connected. After making all connections, turn on the projector and then the other devices. When connecting a computer, ensure that it is the last device to be turned on after all the connections are made.

Ensure that you have read the owner's manuals of the devices to be connected before making connections



* When using the Ø3.5 mm mono audio cable, the volume level will be half of when using the Ø3.5 mm stereo audio cable.




- See page 58 "Computer Compatibility Chart" for a list of computer signals compatible with the projector. Use with computer signals other than those listed may cause some of the functions to not work.
- A Macintosh adaptor may be required for use with some Macintosh computers. Contact your nearest Macintosh Dealer.
- Depending on the computer you are using, an image may not be projected unless the computer's external output port is switched on. Refer to the specific instructions in the owner's manual of your computer to enable your computer's external output port.


Connecting to Video Equipment

The projector is equipped with input terminals that support component, S-video, and video signals. See the illustration below to connect with the audio-visual equipment.


The image quality is highest in the order of the component signal, the S-video signal and the video signal. If your audio-visual equipment has a component output terminal, use the COMPUTER/COMPONENT terminal (INPUT1 or INPUT 2) on the projector for video connection.



When using an S-video cable (INPUT3)




When using a composite video cable (INPUT4)



Connecting to a Monitor with RGB Input Terminal


You can display computer images on both the projector and a separate monitor using two sets of RGB cables.



- **◎** Note
- RGB signals and Component signals can be output to the monitor.
- For this connection, another RGB cable (commercially available) is required.

Controlling the Projector by a Computer

When the RS-232C terminal on the projector is connected to a computer with a DIN-D-sub RS-232C adaptor and an RS-232C serial control cable (cross type, commercially available), the computer can be used to control the projector and check the status of the projector. See page 54 for detail.



RS-232C serial control cable (cross type, commercially available)




- The RS-232C function may not operate if your computer terminal is not correctly set up. Refer to the owner's manual of the computer for details.
- See page 53 for connection of an RS-232C serial control cable.



- Do not connect the RS-232C cable to a port other than the RS-232C terminal on the computer. This may damage your computer or projector.
- Do not connect or disconnect an RS-232C serial control cable to or from the computer while it is on.
 This may damage your computer.

Connecting the Power Cord

Plug the supplied power cord into the AC socket on the rear of the projector.



AC sócket

Turning the Projector On/Off

Turning the Projector on

Note that the connections to external equipment and power outlet should be done before performing the operations written below. (See pages 23 to 26.)

Remove the lens cap and press STANDBY-ON on the projector or ON on the remote control.

 When System Lock is set, the keycode input box appears. To cancel the keycode setting, input the keycode that you have already set. See page 44 for details.



• About the Lamp Indicator

The lamp indicator illuminates to indicate the status of the lamp.

Red: The lamp is on.

Blinking in red: The lamp is warming up or shutting down.

Green: The lamp is shut down abnormally or the lamp should be replaced.


- When switching on the projector, a slight flickering of the image may be experienced within the first minute after the lamp has been illuminated. This is normal operation as the lamp's control circuitry is stabilising the lamp output characteristics. It should not be regarded as faulty operation.
- If the projector is put into standby mode and immediately turned on again, the lamp may take some time to start projection.

Turning the Power off (Putting the Projector into Standby Mode)

- 1 Press STANDBY-ON on the projector or STANDBY on the remote control, then press that button again while the confirmation message is displayed, to put the projector into standby mode.
- 2 Unplug the power cord from the AC outlet after the cooling fan stops.
 - The power indicator on the projector blinks in red while cooling.
 - The power indicator changes to green when the projector finishes cooling.

Info

English is the factory default language. If you
want to change the on-screen display to another
language, change the language according to
the procedure on page 42.



On-screen Display (confirmation message)



Shutting Down, Please Wait.



 Do not unplug the power cord during projection or cooling fan operation. This can cause damage due to rise in internal temperature, as the cooling fan also stops.

Image Projection

About the Setup Guide

After turning on the projector, the Setup Guide screen appears to assist you with projector setup.

Guidance items

- 1 FOCUS
- 2 HEIGHT ADJUST
- 3 ZOOM

Press ENTER to exit the Setup Guide screen.



• The Setup Guide screen automatically highlights the items in the following order:

However, you can adjust the focus, height (angle), or zoom regardless of the highlighted item.

 If you do not want to display the Setup Guide for the next time, set "Menu" - "SCR - ADJ" -"Setup Guide" to "Off". (See page 42.)

Adjusting the Projected Image

1 Adjusting the Focus

You can adjust the focus with the focus ring on the projector.


Rotate the focus ring to adjust the focus while watching the projected image.


2 Adjusting the Screen Size

You can adjust the screen size using the zoom ring on the projector.

Rotate the zoom ring to enlarge or shrink the screen size.

Setup Guide screen





3 Adjusting the Height

The height of the projector can be adjusted using the adjustment feet at the front and rear of the projector.

When the screen is above the projector, the projection image can be made higher by adjusting the projector.

- 1 Lift the projector to adjust its height while lifting the HEIGHT ADJUST lever.
- 2 Remove your hands from the HEIGHT ADJUST lever of the projector after its height has been finely adjusted.
 - The angle of projection is adjustable up to 8 degrees from the surface on which the projector is placed.
- 3 Use the rear adjustment foot to make the projector level.
 - The projector is adjustable ±1 degree from the standard position.



 When adjusting the height of the projector, trapezoidal distortion occurs. Follow the procedures in Keystone Correction to correct the distortion. (See pages 31 and 41.)

Info

- Do not apply too much pressure on the projector when the front adjustment foot comes out.
- When lowering the projector, be careful not to get your fingers caught in the area between the adjustment foot and the projector.
- Hold the projector firmly while lifting or carrying.








Image Projection (Continued)

Switching the Input Mode

Select the appropriate input mode for the connected equipment.

Press INPUT 1, INPUT 2, INPUT 3 or INPUT 4 on the remote control to select the input mode.

- When pressing INPUT (▲/▼) on the projector, input mode switches in the following order:
 ►INPUT1↔INPUT2↔INPUT3↔INPUT4←
- When "Auto Search" is set to "On", INPUT (▲/▼) on the projector functions as the Auto Search buttons. (See page 43.)

Adjusting the Volume

Press ☐/⊕ on the remote control or —◄/▶+ on the projector to adjust the volume.




- Pressing □/ will lower the volume.
- Pressing ⊕/►+ will raise the volume.
- When the projector is connected to external equipment, the volume level of the external equipment changes in accordance with the volume level of the projector. Set the projector's volume to the lowest level when turning the projector on/ off or changing the input signal.
- When you do not want to output the sound from the projector's speaker while the projector is connected to external equipment, set "Speaker" in "PRJ-ADJ" menu to "Off". (See page 43.)

Displaying the Black Screen and Turning off the Sound Temporarily


Press
AV MUTE on the remote control to temporarily display a black screen and turn off the sound.



 Pressing AV MUTE again will turn the projected image back on.



On-screen Display



On-screen Display



Correcting Trapezoidal Distortion

When the image is projected either from the top or from the bottom towards the screen at an angle, the image becomes distorted trapezoidally. The function for correcting trapezoidal distortion is called Keystone Correction.



 The Keystone Correction can be adjusted up to an angle of approximately ±13 degrees and the screen can also be set up to an angle of approximately ±13 degrees (when the resize mode is set to "NORMAL" (see page 32)).

1 Press © KEYSTONE to enter the Keystone Correction mode.

 You can also display the on-screen display of the Keystone Correction mode with ® KEYSTONE on the projector.

Press **▲/▶** or **◄/▼** to adjust the Keystone Correction.

 You can also adjust the Keystone Correction using the adjustment buttons on the projector.




• Press RETURN while the on-screen display of the Keystone Correction mode is on the screen to return to the default setting.

3 Press © KEYSTONE.

- The on-screen display of the Keystone Correction mode will disappear.
- You can also use
 KEYSTONE on the projector.

When using EIP-2500

 The projector automatically detects tilt and the AUTO KEYSTONE feature automatically corrects trapezoidal distortion.




▼ On-screen display (Keystone Correction mode)




Shrinks upper side.

(Move the slide bar in the + direction.)



Shrinks lower side.

(Move the slide bar in the - direction.)





 While adjusting the image using Keystone Correction, straight lines and the edges of the image may appear jagged.

ℕ Note

- Automatic Keystone Correction may not work well in some cases, such as when the screen is leaning, temperature is extremely high or low, or zoom is at maximum or minimum. In these cases, fine adjust the Keystone Correction following steps 1 to 3.
- You can select "On" or "Off" for the Auto Keystone Correction mode. (See page 41.)


Image Projection (Continued)

Resize Mode

This function allows you to modify or customize the resize mode to enhance the input image. Depending on the input signal, you can choose "NORMAL", "BORDER" or "STRETCH" image.

Press @ RESIZE.

• See page 41 for setting on menu screen.



Computer

	NORMAL		BORDER		STRETCH		
		EIP-2500	EIP-200	EIP-2500	EIP-200	EIP-2500	EIP-200
	SVGA (800 × 600)	1024 × 768	800 × 600	768 × 576	600 × 450	1024 × 576	800 × 450
4:3 aspect ratio	XGA (1024 × 768)						
	SXGA (1280 × 960)						
	SXGA + (1400 × 1050)						
Other aspect ratios	SXGA (1280 × 1024)	1024 × 768	800 × 600	768 × 576	600 × 450	1024 × 576	800 × 450
	1280 × 720	-	-	-	-	1024 × 576	800 × 450

Input Signal			Output screen image			
Computer		Image type	NORMAL	BORDER	STRETCH	
EIP-2500	EIP-200	illiage type	NORWAL	BONDEN	SINEIUN	
Resolution lower than XGA	Resolution lower than SVGA					
XGA	SVGA	4:3 aspect ratio	*	*		
Resolution higher than XGA	Resolution higher than SVGA					
SXGA (1280×1024)		5:4 aspect ratio				
1280×720		16:9 aspect ratio			*	

^{*} Mode for projecting an image with the original aspect ratio without cutting any portions.

[:] Cutout area on which images cannot be projected.

VIDEO


• "STRETCH" is fixed when 540P, 720P or 1080I signals are entered.

Input Signal		Output screen image		
DVD / Video	Image type	NORMAL	BORDER	STRETCH
	4:3 aspect ratio	*	*	
480I, 480P, 576I,	Letter box	*	*	
576P, NTSC, PAL, SECAM	Squeezed 16:9 image			*
	Squeezed 4:3 image			*
540P, 720P, 1080I	16:9 aspect ratio			*
	16:9 aspect ratio (4:3 aspect ratio in 16:9 screen)			*

^{*} Mode for projecting an image with the original aspect ratio without cutting any portions.

[:] Cutout area on which images cannot be projected.
: Area on which the image is not included in the original signals.

Operating with the Remote Control



Auto Sync (Auto Sync Adjustment)

Auto Sync function works when detecting input signal after the projector turns on.

Press AUTO SYNC to manually adjust with Auto Sync function.



 When the optimum image cannot be achieved with Auto Sync adjustment, use the help menu for manual adjustments. (See page 46.)

Displaying and Setting the Break Timer

1 Press 🕏 BREAK TIMER.

The timer starts to count down from 5 minutes.

▼On-screen display



Press ▲/▼/◀/► to adjust the length of the break time.

• Increases with ▲ or ► 5 minutes → 6 minutes → 60 minutes

Shortens with ◀ or ▼

4 minutes → 3 minutes →1 minute • The break time can be set in units of one

minute (up to 60 minutes).

Canceling the break time display function

Press BREAK TIMER.



Break Timer does not function while the projector is operating the "Auto Sync", "FREEZE" or "AV MUTE" functions.

Freezing a Moving Image

1 Press

Press
FREEZE.

The projected image is frozen.

2

Press FREEZE again to return to the moving image from the currently connected device.

Selecting the Picture Mode


You can select the appropriate picture mode for the projected image, such as movie or video game.

Press PICTURE MODE.




- See page 39 for details on the picture mode.
- * "sRGB" is displayed only when RGB signal is input.


Menu Items



Menu Items (Continued)

"Projection adjustment (PRJ-ADJ)" menu





"Help" menu



The items you can set with "Help" menu

"Help" menu → Page 46

 Vertical stripes or flickering image appear Auto Sync

Adjust vertical noise

Adjust horizontal noise

· Data image is not centered

Auto Sync H-Pos

V-Pos

Color is faded or poor

Signal type: Auto/RGB/Component


INPUT 1 or INPUT 2 INPUT 3 or INPUT 4

Video System: A u t o / P A L / S E C A M / NTSC3.58/NTSC4.43/PAL-

M/PAL-N/PAL-60

* The selectable items vary depending on the input signal and the selected input mode.

Using the Menu Screen



Menu Selections (Adjustments)


Example: Adjusting "Bright".

- This operation can also be performed by using the buttons on the projector.
- Press MENU.

 The "Picture" menu screen for the selected input mode is displayed.
- Press ▶ or ◀ and select "Picture" to adjust.


Example: "Picture" screen menu for INPUT 1 (RGB) mode

Menu item



Using the Menu Screen (Continued)

- Press ▲ or ▼ and select "Bright" to adjust.
 - The selected item is highlighted.



To adjust the projected image while watching it

Press ENTER.

- The selected item (e.g. "Bright") is displayed by itself at the bottom of the screen.
- When pressing ▲ or ▼, the following item ("Red" after "Bright") will be displayed.



Off

The item displayed by itself

Auto Keystone


Picture		
Bright	[0] 🔯 –	+ 🔆
◆SEL./ADJ.	← Rtn. Menu	■END



 Press ENTER again to return to the previous screen.

4 Press ◀ or ▶ to adjust the item selected.

• The adjustment is stored.



Press
MENU/HELP.

The menu screen will disappear.




 Menu buttons do not function while the projector is operating the "Auto Sync", "Break Time", "FREEZE", or "AV MUTE" functions.


Picture Adjustment ("Picture" menu)

Menu operation → Page 37

► Example: "Picture" screen menu for INPUT 1 (RGB) mode



Example: "Picture" screen menu for INPUT 3 mode



1 Selecting the Picture Mode

Selectable items	Description	The default settings of each item when selecting Picture Mode		
Selectable items	Description	CLR Temp	Bright Boost	Lamp Setting
Standard	For standard image	7500K	1	Bright
Presentation	Brightens portions of image for more enhanced presentations.	7500K	2	Bright
Movie	Gives natural tint to the projected image.	6500K	0	Eco + Quiet
Game	Gives sharpness to the projected image.	7500K	2	Bright
*sRGB	For high fidelity reproduction of images from a computer.	-	-	Bright

- "sRGB" is displayed only when RGB signal is input.
- You can set or adjust each item in the "Picture" menu to your preference. Any changes you make are retained in memory.

Note

- You can also press PICTURE MODE on the remote control to select the picture mode. (See page 34.)
- *sRGB is an international standard of color reproduction regulated by the IEC (International Electrotechnical Commission). As the fixed color area has been decided by the IEC, the images are displayed in a natural tint based on an original image, when "sRGB" is selected. For additional information about the sRGB function, visit "http://www.srgb.com/".

You cannot set the items, "Red", "Blue", "CLR Temp", "Bright Boost", when "sRGB" is selected.



 When "sRGB" is selected, the projected image may become dark, but this does not indicate a malfunction.

Picture Adjustment ("Picture" menu) (Continued)

Menu operation → Page 37

2 Adjusting the Image

Adjustment Items	◄ button	▶ button
Contrast	For less contrast.	For more contrast.
Bright	For less brightness.	For more brightness.
Red*1	For weaker red.	For stronger red.
Blue*1	For weaker blue.	For stronger blue.
Color*2	For less color intensity.	For more color intensity.
Tint*2*3	For making skin tones purplish.	For making skin tones greenish.
Sharp*2	For less sharpness.	For more sharpness.
Bright Boost*1	For high fidelity color reproduction.	For more vividness.

- *1 Not adjustable/selectable when selecting "sRGB".
- *2 Not displayed in the RGB input mode.
- *3 "Tone" will appear on the menu screen only when PAL or SECAM signals are input (including when forcibly changed to those input signals). There is basically no need to adjust "Tone", but you can adjust the picture tone with this adjustment when inputting PAL or SECAM signals.

Note

- "Bright Boost" and "CLR Temp" cannot be set when "sRGB" is selected.
- To reset all adjustment items, select "Reset" and press ENTER.

③ Adjusting the Color Temperature

Selectable items	Description
5500K 6500K 7500K 8500K 9300K	For lower color temperature for warmer, reddish incandescent-like images.
10500K	For higher color temperature for cooler, bluish, fluorescent-like images.

Note

 Values on "CLR Temp" are only for general standard purposes.

4 Progressive

Selectable items	Description
2D Progressive	Useful to display fast-moving images such as sports.
3D Progressive	Useful to display relatively slow- moving images such as drama and documentary more clearly.
Film Mode	Reproduces the image of film source* clearly. Displays the optimized image of film transformed with three-two pull down (NTSC and PAL60Hz) or two-two pull down (PAL50Hz and SECAM) enhancement to progressive mode images.

* The film source is a digital video recording with the original encoded as is at 24 frames/second. The projector can convert this film source to progressive video at 60 frames/second with NTSC and PAL60Hz or at 50 frames/second with PAL50Hz and SECAM to play back a high-definition image.

- In NTSC or PAL60Hz, even if the 3D Progressive mode has been set, the three-two pull down enhancement will be enabled automatically when the film source has been entered.
- When the image is blurred or noisy, switch to the optimal mode.
- When using progressive inputs, inputs are directly displayed so that 2D Progressive, 3D Progressive and Film Mode cannot be selected.

⑤ Lamp Setting


Select- able items	Bright- ness	Fan sound	Power consumption (When using AC 100V)	Lamp Life
Eco + Quiet	Approx. 87%	Low	305W	Approx. 3,000 hours
Bright	100%	Normal	350W	Approx. 2,000 hours

⊗Note

 When "Lamp Setting" is set to "Eco+Quiet", the power consumption will decrease and the lamp life will extend. (Projection brightness decreases approximately 13%.)

Adjusting the Projected Image ("SCR - ADJ" menu)

Menu operation → Page 37



*"Auto Keystone" can be operated only when using EIP-2500.


1 Setting the Resize Mode

Note 🌕

- For details of the Resize mode, see pages 32 and 33.
- You can also press TRESIZE on the remote control to set the resize mode. (See page 32.)

② Adjusting the Image Position

You can move the projected image vertically.





 You cannot set this item when "Resize" is set to "Normal".

③ Keystone Correction

When the image is projected either from the top or from the bottom towards the screen at an angle, the image becomes distorted trapezoidally. The function for correcting trapezoidal distortion is called Keystone Correction.

■ When using EIP-2500


For Auto Keystone Correction

Set "Auto Keystone" on the "SCR - ADJ" menu to "On".

For Manual Keystone Correction

Set "Auto Keystone" on the "SCR - ADJ" menu to "Off", select "Keystone", and then adjust with the slide bar.

Manual Correction



■ When using EIP-200

Select "Keystone" on the "SCR-ADJ" menu and adjust with the slide bar.

See page 31 for details of Keystone Correction.



 The Keystone Correction can be adjusted up to an angle of approximately ±13 degrees with the "Auto Keystone" and up to an angle of approximately ±13 degrees with the manual "Keystone" (when "Resize" is set to "Normal").

Adjusting the Projected Image ("SCR - ADJ" menu) (Continued)

Menu operation → Page 37

Setting On-screen Display

Selectable items	Description
On	All On-screen Displays are displayed.
Off	INPUT/VOLUME/AV MUTE/FREEZE/ AUTO SYNC/RESIZE/PICTURE MODE/ "An invalid button has been pressed." are not displayed.

Reversing/Inverting Projected Images

Selectable items	Description
Front	Normal image (Projected from the front of the screen)
Ceiling + Front	Inverted image (Projected from the front of the screen with an inverted projector)
Rear	Reversed image (Projected from the rear of the screen or with a mirror)
Ceiling + Rear	Reversed and inverted image (Projected with a mirror)

See page 19 for details of Projection (PRJ) Mode.

(5) Selecting the Background Image

Selectable items	Description
Logo	EIKI logo screen
Blue	Blue screen
None	_

6 Selecting the Setup Guide


Selectable items	Description
On	Displaying the Setup Guide when turning the projector on.
Off	Not displaying the Setup Guide.

8 Selecting the On-screen Display Language

The projector can switch the on-screen display language among 11 languages.

Adjusting the Projector Function ("PRJ - ADJ" menu)

Menu operation → Page 37



1 Auto Search Function

This function automatically searches for and switches to the input mode in which signals are being received, when the projector is turned on, or when the INPUT button is pressed.



When "Auto Search" is set to "On"

- If two or more input signals are found, the projector selects the input source in the order of INPUT 1 → INPUT 2 → INPUT 3 → INPUT 4 when you press INPUT (▲/▼) on the projector.
- While "Auto Search" is set to "On", press
 INPUT 1, INPUT 2, INPUT 3 or
 INPUT 4 on the remote control to select an input mode other than the input mode selected by the projector.

② Auto Sync (Auto Sync Adjustment)

Selectable items	Description
On	Auto Sync adjustment will occur when the projector is turned on or when the input signals are switched, when connected to a computer.
Off	Auto Sync adjustment is not automatically performed.

Note Note

- Auto Sync adjustment is also performed by pressing AUTO SYNC on the remote control.
- The Auto Sync adjustment may take some time to complete, depending on the image of the computer connected to the projector.
- When the optimum image cannot be achieved with Auto Sync adjustment, use manual adjustments. (See page 46.)

3 Auto Power Off Function

Selectable items	Description	
On	When no input signal is detected for more than 15 minutes, the projector will automatically enter standby mode.	
Off	The Auto Power Off function will be disabled.	

Note 🌑

 When the Auto Power Off function is set to "On", 5 minutes before the projector enters standby mode, the message "Enter STANDBY mode in X min." will appear on the screen to indicate the remaining minutes.

4 Setting the Confirmation Sound (System Sound)

Selectable items	Description	
On	A confirmation sound is made when the projector turns on/off.	
Off	No confirmation sound is made.	

⑤ Speaker Setting

Selectable items	Description
On	The audio signal is output from the internal speaker.
Off	The audio signal is not output from the internal speaker.

Adjusting the Projector Function ("PRJ - ADJ" menu) (Continued)

Menu operation → Page 37

6 Selecting the Transmission Speed (RS-232C)

Make sure that both the projector and computer are set for the same baud rate.

Selectable items	Description
9600bps	Transmission speed is slow.
	‡
115200bps	Transmission speed is rapid.

7 Fan Mode Setting

This function changes the fan rotation speed.

Selectable items	Description
Normal	Suitable for normal environments.
High	Select this when using the projector at altitudes of approximately 1,500 meters (4,900 feet) or more.

When "Fan Mode" is set to "High", the fan rotation speeds up, and the fan noise becomes louder.

Checking the Lamp Life Status

You can confirm the cumulative lamp usage time and the remaining lamp life (percentage).

Lamp usage condition		Remaining lamp life	
	"Life"	100%	5%
Operated exclusively with Lamp Setting set to "Eco +Quiet"		Approx. 3,000 hours	Approx. 150 hours
Operated exclusively with Lamp Setting set to "Bright"		Approx. 2,000 hours	Approx. 100 hours

⊗Note

- It is recommended that the lamp be changed when the remaining lamp life becomes 5%.
- The lamp life may vary depending on the usage condition.

8 System Lock Function

This function prevents unauthorized use of the projector. Once this function is activated, users must enter the correct keycode each time the projector is turned on. We suggest you record the keycode in a safe place where only authorized users have access.

Ir

 If you lose or forget your keycode, contact your nearest EIKI Authorized Dealer or Service Center. Even if the product warranty is valid, the keycode reset will incur a charge.

Setting/Changing the keycode

- 1 Press the 4 buttons on the remote control or on the projector to enter the preset keycode in "Old Code".
 - When setting the keycode for the first time, press ▼ on the projector for four times.



🗞 Note

- If you input a wrong keycode, the cursor returns to the first point of the "Old Code".
- The preset keycode is 4 ▼ buttons on the projector. When you press the ▼ button four times, the keycord input screen disappears.

Press the 4 buttons on the remote control or on the projector to enter the new keycode in "New Code".



- You can not use the following buttons for keycode:
 - STANDBY-ON (on the projector)
- ON ON
- STANDBY
- 🗗 ENTER
- 🕾 RETURN
- MENU/HELP
- System lock function recognizes each button on the remote control or on the projector as an individual button, even if they share the same button name. If you used the buttons on the projector in setting your keycode, the keycode cannot be canceled with the remote control.



3 Enter the same keycode in "Reconfirm".




To cancel the keycode that you have already set

 Press ▼ on the projector for four times in steps 2 and 3 above.

When the System Lock is set

 When System Lock is set, the keycode input screen appears after the power is turned on.
 When it appears, enter the right keycode to start projection.

Input screen for keycode



Locking the Operation Buttons on the Projector (Keylock Function)

Use this function to lock the operation buttons on the projector.

■ Locking the Operation Buttons

Hold down ENTER on the projector for about 5 seconds while the projector is being turned on.

▼On-screen Display

Keylock function ON

- The keylock function does not affect the operation with the remote control buttons.
- You cannot use the keylock function while the projector is warming up.

■ Taking the Keylock off

Hold down ENTER on the projector for about 5 seconds.

▼On-screen Display

Keylock function OFF

 When the projector is in standby mode, you can release the keylock by holding down
 ENTER and STANDBY-ON on the projector simultaneously for about 5 seconds.



 Keylock does not function while the projector is: displaying the "Setup Guide" or "Menu" screens, in standby mode, warming up, changing input signals, operating "Auto Sync" function, in "FREEZE" mode or on the "System Lock" screen during warming up.

Troubleshooting with "Help" menu

This function advises you to solve the problems during usage.


Utilizing "Help" menu functions

ckering appears
e flickering when pro-B signal.

Example: When image flickering appears

Operation to solve image flickering when projecting the computer RGB signal.

- 1 Press
 MENU/HELP.
- Press ◀ or ▶ to select "Help", then press ← ENTER.
- Press ▲ or ▼ to select "Vertical stripes or flickering image appears" on Help menu, then press ← ENTER.



Select "Initiate "Auto Sync" Adjustments", then press — ENTER.

Adjustment buttons $(\triangle/\nabla/\triangle/\triangle)$

- If the image is not improved, select "Adjust horizontal noise.", then press -ENTER.
- 6 Press **◄** or **▶** to adjust.






- You can adjust the items with check marks (✔).
- The items in the "Help" menu change, depending on the input signal or setting that you have selected.
- If the problem is not solved, refer to "Troubleshooting". (see pages 59 and 60)
- When selecting "sRGB" in "Picture Mode", the item "Color is faded or poor" is not displayed. This means you cannot change input signal types.

Maintenance


Cleaning the projector

- Ensure that you have unplugged the power cord before cleaning the projector.
- The cabinet as well as the operation panel is made of plastic. Avoid using benzene or thinner, as these can damage the finish on the cabinet.
- Do not use volatile agents such as insecticides on the projector.
 - Do not attach rubber or plastic items to the projector for long periods.
 - The effects of some of the agents in the plastic may cause damage to the quality or finish of the projector.
- Wipe off dirt gently with a soft flannel cloth.
- When the dirt is hard to remove, soak a cloth in a mild detergent diluted with water, wring the cloth well and then wipe the projector. Strong cleaning detergents may discolor, warp or damage the coating on the projector. Make sure to test on a small, inconspicuous area on the projector before use.




Cleaning the lens

- Use a commercially available blower or lens cleaning paper (for glasses and camera lenses) for cleaning the lens. Do not use any liquid type cleaning agents, as they may wear off the coating film on the surface of the lens.
- As the surface of the lens can easily get damaged, be sure not to scrape or hit the lens.



Cleaning the exhaust and intake vents

■ Use a vacuum cleaner to clean dust from the exhaust vent and the intake vent.






• If you want to clean the air vents during projector operation, be sure to press @STANDBY-ON on the projector or @STANDBY on the remote control and put the projector into standby mode. After the cooling fan has stopped, clean the vents.

Maintenance Indicators

- The warning lights (power indicator, lamp indicator and temperature warning indicator) on the projector indicate problems inside the projector.
- If a problem occurs, either the temperature warning indicator or the lamp indicator will illuminate red, and the projector will enter standby mode. After the projector has entered standby mode, follow the procedures given below.

Top View



About the temperature warning indicator



TEMP.

If the temperature inside the projector increases, due to blockage of the air vents, or the setting location, "TEMP." will illuminate in the lower left corner of the picture. If the temperature keeps on rising, the lamp will turn off and the temperature warning indicator will blink, the cooling fan will run, and then the projector will enter standby mode. After "TEMP." appears, be sure to perform the measures described on page 49

About the lamp indicator



Change The Lamp.

- When the remaining lamp life becomes 5% or less,

 (yellow) and "Change The Lamp" will be displayed on the screen. When the percentage becomes 0%, it will change to
 (red), the lamp will automatically turn off and then the projector will automatically enter standby mode. At this time, the lamp indicator will illuminate in red.
- If you try to turn on the projector a fourth time without replacing the lamp, the projector will not turn on.

Indicators on the Projector

Power indicator	Green on	Normal (Standby)
	Red on	Normal (Power on)
	Green blinks	Abnormal (See page 49.)
	Red blinks	Normal (Cooling)
Lamp indicator	Green on	Normal
	Green blinks	The lamp is warming up or shutting down.
	Red on	The lamp is shut down abnormally or requires to be changed. (See page 49.)
Temperature warning indicator	Off	Normal
	Red on	The internal temperature is abnormally high. (See page 49.)

Maintenance indicator		Problem Cause	Possible Solution			
	Normal	Abnormal				
Tempera- ture warning indicator	Off	Red on (Standby)	The internal temperature is abnormally high.	Blocked air intake	Relocate the projector to an area with proper ventilation. (see page 8)	
				Cooling fan breakdown Internal circuit failure Clogged air intake	Take the projector to your nearest EIKI Authorized Dealer or Service Center for repair.	
Lamp indicator	Green on (Green blinks	Red on	The lamp does not illuminate.	The lamp is shut down abnormally.	Disconnect the power cord from the AC outlet, and then connect it again.	
	when the lamp is warming		Time to change the lamp.	Remaining lamp life becomes 5% or less.	 Carefully replace the lamp. (See page 51.) Take the projector to your 	
	up or turning off.)	Red on (Standby)	The lamp does not illuminate.	Burnt-out lamp Lamp circuit failure	nearest EIKI Authorized Dealer or Service Center for repair. Please exercise care when replacing the lamp. Securely install the cover.	
Power indicator	Green on/ Red on Red blinks (Cooling)	Green blinks	The power indicator blinks in green when the projector is on.	The lamp unit cover is open.	If the power indicator blinks in green even when the lamp unit cover is securely installed, contact your nearest EIKI Authorized Dealer or Service Center for advice.	



- If the temperature warning indicator illuminates, and the projector enters standby mode, follow the possible solutions above and then wait until the projector has cooled down completely before plugging in the power cord and turning the power back on. (At least 10 minutes.)
- If the power is turned off for a brief moment due to power outage or some other cause while using the projector, and the power supply recovers immediately after that, the lamp indicator will illuminate in red and the lamp may not be lit. In this case, unplug the power cord from the AC outlet, replace the power cord in the AC outlet and then turn the power on again.
- The cooling fan keeps the internal temperature of the projector constant and this function is controlled automatically. The sound of the cooling fan may change during operation because the fan speed may change and this is not a malfunction.
- Do not unplug the power cord after the projector has entered standby mode and while the cooling fan is running. The cooling fan runs for about 90 seconds.

Regarding the Lamp

Lamp

- It is recommended that the lamp (sold separately) be replaced when the remaining lamp life becomes 5% or less, or when you notice a significant deterioration in the picture and color quality. The lamp life (percentage) can be checked with the on-screen display. (see page 44)
- Purchase a replacement lamp of type AH-66271/AH-15001 from your place of purchase, nearest EIKI Authorized Dealer or Service Center.

Caution Concerning the Lamp

- This projector utilizes a pressurized mercury lamp. A loud sound may indicate lamp failure. Lamp failure can be attributed to numerous sources such as: excessive shock, improper cooling, surface scratches or deterioration of the lamp due to a lapse of usage time.
 - The period of time up to failure largely varies depending on the individual lamp and/or the condition and the frequency of use. It is important to note that failure can often result in the bulb cracking.
- When the lamp replacement indicator and on-screen display icon are illuminated, it is recommended that the lamp be replaced with a new one immediately, even if the lamp appears to be operating normally.
- Should the lamp break, there is also a possibility that glass particles may spread inside of the projector. In such a case, it is recommended you contact your nearest EIKI Authorized Dealer or Service Center to assure safe operation.
- Should the lamp break, the glass particles may spread inside the lamp cage or gas contained in the lamp may be vented into the room from the exhaust vent. Because the gas in this lamp includes mercury, ventilate the room well if the lamp breaks and avoid all exposure to the released gas. In case of exposure to the gas, consult a doctor as soon as possible.

Replacing the Lamp



- Do not remove the lamp unit from the projector right after use. The lamp will be very hot and may cause burn or injury.
- Carefully change the lamp by following the instructions described in this section. * If you wish, you may have the lamp replaced at your nearest EIKI Authorized Dealer or Service Center.
- * If the new lamp does not light after replacement, take your projector to the nearest EIKI Authorized Dealer or Service Center for repair.

Removing and Installing the Lamp Unit

⚠Warning!

Do not remove the lamp unit from the projector right after use. The lamp and parts around the lamp will be very hot and may cause burns or injury.







Lamp unit AH-66271 (for EIP-2500) AH-15001 (for EIP-200)



Info

- Make sure that you remove the lamp unit by the handle. Do not touch the glass surface of the lamp unit or the inside of the projector.
- To avoid injury to yourself and damage to the lamp, be sure to carefully follow the steps below.
- Do not loosen other screws except for the lamp unit cover and lamp unit.
- Press STANDBY-ON on the projector or STANDBY on the remote control to put the projector into standby mode.
 - Wait until the cooling fan stops.
- 2 Disconnect the power cord.
 - Unplug the power cord from the AC socket.
 - Leave the lamp until it has fully cooled down (about 1 hour).
- 3 Remove the lamp unit cover.
 - Turn the projector over. Loosen the user service screw (1) that secures the lamp unit cover. Remove the lamp unit cover (2).





Regarding the Lamp (Continued)

Remove the lamp unit.

• Loosen the securing screws from the lamp unit. Hold the lamp unit by the handle and pull it in the direction of the arrow. At this time, keep the lamp unit horizontal and do not tilt it.

Insert the new lamp unit.

 Press the lamp unit firmly into the lamp unit compartment. Fasten the securing screws.

Replace the lamp unit cover.

• Align the tab on the lamp unit cover (1) and place it while pressing the tab (2) to close it. Then tighten the user service screw to secure the lamp unit cover.



Info

• If the lamp unit and lamp unit cover are not correctly installed, the power will not turn on, even if the power cord is connected to the projector.

Resetting the Lamp Timer

Reset the lamp timer after replacing the lamp.



Info


• Make sure to reset the lamp timer only when replacing the lamp. If you reset the lamp timer and continue to use the same lamp, this may cause the lamp to become damaged or explode.


Connect the power cord.

• Plug the power cord into the AC socket of the projector.

Reset the lamp timer.


- While simultaneously holding down ■MENU/HELP. ■ENTER and ▼ on the projector, press @STANDBY-ON on the projector.
- "LAMP 0000H" is displayed, indicating that the lamp timer is reset.











Connecting Pin Assignments

COMPUTER-RGB/COMPONENT INPUT1, 2 and COMPUTER-RGB/COMPONENT OUTPUT Terminals:

15-pin Mini D-sub female connector

11 15 (0) (0) ••••• 1 5 10


COMPUTER-RGB Input/Output

- Video input (red)
- 2 Video input (green/sync on green)
- 3. Video input (blue)
- 4. Not connected
- 5. Not connected
- 6. Earth (red)
- 7. Earth (green/sync on green)
- Earth (blue)
- 9. Not connected
- 10. GND
- 11. Not connected Bi-directional data
- 13. Horizontal sync signal: TTL level 14. Vertical sync signal: TTL level
- 15. Data clock

Component Input/Output

- PR (CR) 1.
- 2
- 3. PB (CB)
- 4. Not connected
- 5. Not connected
- Earth (PR)
- 7. Earth (Y)
- Earth (PB) Not connected
- 10. Not connected
- 11. Not connected
- 12. Not connected
- Not connected
- Not connected
- 15. Not connected

RS-232C Terminal: 9-pin Mini DIN female connector



Pi	n No.	Signal	Name
	2. 3. 4.	RD SD	Receive Data Send Data
3	4. 5. 6.	SG	Signal Ground
	6. 7. 8. 9.	RS CS	Request to Send Clear to Send

Reference

I/O

Input

Output

Not connected

Connected to internal circuit Connected to internal circuit

Not connected


Connected to internal circuit

Not connected

Connected to CS in internal circuit Connected to RS in internal circuit

Not connected

RS-232C Terminal: 9-pin D-sub male connector of the DIN-D-sub RS-232C adaptor



	O.g. ia.
1. 2. 3.	RD
	SD
4.	
5.	SG
6. 7.	RS
7. 8.	CS
9.	00

Signal	Name	I/O
RD SD	Receive Data Send Data	Input Output
SG	Signal Ground	
RS CS	Request to Send Clear to Send	

Reference Not connected

Connected to internal circuit Connected to internal circuit

Not connected


Connected to internal circuit Not connected

Connected to CS in internal circuit

Connected to RS in internal circuit

Not connected

RS-232C Cable recommended connection: 9-pin D-sub female connector



Downloaded From projector-manual.

1. 2. 3. 4. 5. 6. 7. 8.	CD RD SD ER SG DR RS CS CI	1 2 3 4 5 6 7 8 9
9.	CI	9

in No.	Signal
1.	CD
2.	RD
3.	SD
4.	ER
5.	SG
6.	DR
7.	RS
8.	CS

ČĬ

 Depending on the controlling device used, it may be necessary to connect Pin 4 and Pin 6 on the controlling device (e.g. computer).

Projector	Computer
Pin No.	Pin No.
4	<u> </u>
com EKI Manuals	
com EKI Manuals	<u> </u>

RS-232C Specifications and Command Settings

Computer control

A computer can be used to control the projector by connecting an RS-232C serial control cable (cross type, sold separately) to the projector. (See page 26 for connection.)

Communication conditions

Set the serial port settings of the computer to match that of the table.

Signal format: Conforms to RS-232C standard. Parity bit: None Baud rate: * 9,600 bps/115,200 bps Stop bit: 1 bit


* Set the projector's baud rate to the same rate as used by the computer.

Basic format

Commands from the computer are sent in the following order: command, parameter, and return code. After the projector processes the command from the computer, it sends a response code to the computer.

Command format

Data length: 8 bits



Return code (0DH)

Flow control: None

Response code format

Normal response

Problem response (communication error or incorrect command)

Return code (0DH)

E R R

Return code (0DH)



Info

- When controlling the projector using RS-232C commands from a computer, wait for at least 30 seconds after the power has been turned on, and then transmit the commands.
- When more than one code is being sent, send each command only after the response code for the previous command from the projector is verified.
- "POWR????" "TABN _ _ 1" "TLPS _ _ 1" "TPOW _ _ 1" "TLPN _ _ 1" "TLTT _ _ 1" "TLTL _ _ 1" "TNAM _ _ 1" "MNRD _ _ 1" "PJN0 _ _ 1"

When the projector receives a command shown above:

- * The on-screen display will not disappear.
- * The "Auto Power Off" timer will not be reset.



- If an underbar (_) appears in the parameter column, enter a space.
- If an asterisk (*) appears in the parameter column, enter a value in the range indicated in brackets under Control Contents.
- *1 For setting the projector name, send the commands in the order of PJN1, PJN2 and PJN3.
- *2 Parameters of CLR Temp settings are as follows.

CLR Temp	Parameter	CLR Temp	Parameter
5500K	_0 5 5	8500K	_0 8 5
6500K	_065	9300K	_093
7500K	_075	10500K	_1 0 5

Commands

Example: When turning on the projector, make the following setting.

Computer



										RETURN	
CONTROL CONTENTS		MN	IAN	ID	PAI	RAI	ΛE	TEF	3	Power ON	Standby mode (or 40-second startur
Power Off	Р	0	W	R	_	_	-	0		OK or ERR	OK
Power On		0						1		OK	OK or ERR
Power Status				R	-	?	?	-	-	1	0
Projector Condition	Т	Α	В	N	-	_	-	1		0 : Normal,	0 : Normal,
										1 : Temp High,	1 : Temp High,
										8 : Lamp Life 5% or less,	2 : Fan Error,
										16 : Lamp Burnt-out,	4 : Lamp Cover Open,
									ŀ	32 : Lamp Ignition Failure	8 : Lamp Life 5% or less
											16 : Lamp Burnt-out,
											32 : Lamp Ignition Failu
			_				L	1.	+		64 : Temp Abnormally F
Lamp Status		F				.÷.	-	1		0: Off, 1: On, 2: Retry, 3: Waiting, 4: Lamp Erro	
Lamp Power Status		Р			-	_	F	1		1 : On, 2 : Cooling, 3 : Shutting Down	0 : Standby
Lamp Quantity		L			-	_	Ŀ	1		1 0 0000 (laterary)	
Lamp Usage Time (Hour)		L			H	-	-	1		0 – 9999 (Integer)	
Lamp Life (Percentage) Model Name Check		N			H	-	-	1		0% – 100% (Integer) EIP200 / EIP2500	
Model Name Check Model Name Check	M				H	-	-	1		EIP-200 / EIP-2500 EIP-200 / EIP-2500	
Projector Name Setting 1	P				-	*	-			OK or ERR	
(First four characters) *1	۲	٦	IN	'				"		UK UI EKK	
Projector Name Setting 2	 P	j	i.i			*		*	1	OK or ERR	
(Middle four characters) *1	г	٦	IV	۷						OK OF ENN	
Projector Name Setting 3	 P	7	N.		*	*	*	*	1	OK or ERR	
(Last four characters) *1	r	1	14	J						OK OI ERN	
Projector Name Check	Р	1	N	Λ	H		H	1	$^{+}$	Projector Name	
INPUT 1 (RGB1)		R			H	-	H	-	-	OK or ERR	ERR
INPUT 2 (RGB2)		R				·=·	-	2	1	OK or ERR	ERR
INPUT RGB Check		R			?	?	?			1 : RGB1 (INPUT1), 2 : RGB2 (INPUT2), ERR	
INPUT 3 (Video1)		٧			Ė	•	H	1		OK or ERR	ERR
INPUT 4 (Video2)		v				·=·	[=	2		OK or ERR	ERR
INPUT Video Check		٧		D	?	?	?			1 : Video1 (INPUT3), 2 : Video2 (INPUT4), ERR	ERR
INPUT Mode Check		М		D		?	?			1 : RGB, 2 : Video	ERR
INPUT Check		С					?			1 : INPUT1, 2 : INPUT2, 3 : INPUT3, 4 : INPUT4	ERR
INPUT 1 Adjustment Reset	R							1		OK or ERR	ERR
INPUT 2 Adjustment Reset	R				Ī		Ē	1	Ť	OK or ERR	ERR
INPUT 3 Adjustment Reset	٧	Α	R	Ε	_	_	_	1	T	OK or ERR	ERR
INPUT 4 Adjustment Reset	٧	В	R	Ε	_	_	_	1	Ť	OK or ERR	ERR
All Reset	Α	L	R	Ε		_	_	1	T	OK or ERR	ERR
Volume (0 – 60)		0			_	_	*	*		OK or ERR	ERR
Volume up / down (-10 - +10)	٧	0	U	D	_	*	*	*	T	OK or ERR	ERR
Keystone	K	Е	Υ	S	-	*	*	*	Τ	OK or ERR	ERR
(-127 - +127 (EIP-2500) / -100 - +100 (EIP-200))											
AV Mute Off		М			-			0		OK or ERR	ERR
AV Mute On		M		K	_	_	_	1		OK or ERR	ERR
Freeze Off		R		Z	ļ. .	. - .	-	0		OK or ERR	ERR
Freeze On		R		Z	_	_	_	1		OK or ERR	ERR
Auto Sync Start		D			-	_	-	1		OK or ERR	ERR
INPUT 1 Resize : Normal				R		ļ		. 1	. .	OK or ERR	ERR
INPUT 1 Resize : Stretch				R			-	2	1	OK or ERR	ERR
INPUT 1 Resize : Border	-			R	L-	_	Ŀ	6	+	OK or ERR	ERR
INPUT 2 Resize : Normal				R		. . .	-	1		OK or ERR	ERR
INPUT 2 Resize : Stretch				R		ļ	-	2	1	OK or ERR	ERR
INPUT 2 Resize : Border				R	-	_	-	6		OK or ERR	ERR
INPUT 3 Resize : Normal				۷		ļ	-	1		OK or ERR	ERR
INPUT 3 Resize : Stretch				۷	ļ ļ			3	1	OK or ERR	ERR
INPUT 3 Resize : Border				۷	-	_	L	-	+	OK or ERR	ERR
INPUT 4 Resize : Normal				۷			-	1		OK or ERR	ERR
INPUT 4 Resize : Stretch				۷	[. .		-	3	1	OK or ERR	ERR
INPUT 4 Resize : Border		В		۷	L	_	l-	-	-	OK or ERR	ERR
INPUT 1 Picture Mode; Standard	ıR.	A	P	S	Ή	K	1	NA	h	OK or ERR	ERR

RS-232C Specifications and Command Settings (Continued)

								RETURN			
CONTROL CONTENTS		MMC	MAN	D	PAF	RAN	ИΕТ	ER	Power ON	Standby mode (or 40-second startup time)	
INPUT 1 Picture Mode : Presentation	R	Α		S	1	1	OK or ERR	ERR	
INPUT 1 Picture Mode : Movie	R	Α		S	. . .	-	1	2	OK or ERR	ERR	
INPUT 1 Picture Mode : Game	R	Α		S	. .	Ξ.	1	3	OK or ERR	ERR	
INPUT 1 Picture Mode : sRGB	R	A		S	-	_	1	4	OK or ERR	ERR	
INPUT 1 Contrast (- 30 - + 30)	R	Α		1	-	*	*	*	OK or ERR	ERR	
INPUT 1 Bright (-30 - +30)	R		В		-	*	*	_	OK or ERR	ERR	
INPUT 1 Color (- 30 - +30)	R		C		-	*	*	Ŷ	OK or ERR OK or ERR	ERR	
INPUT 1 Tint (- 30 - +30)	R	A	T	I D	-	*	*	*	OK OF ERR	ERR ERR	
INPUT 1 Red (-30 - +30) INPUT 1 Blue (-30 - +30)	R			_	-	*	*	*	OK or ERR	ERR	
INPUT 1 Sharp (-30 - +30)	n R		S		-	*	*	*	OK or ERR	ERR	
INPUT 1 CLR Temp *2		A			-	*	*	*	OK or ERR	ERR	
INPUT 1 Bright Boost (0 – 2)	R	Α		Ė	-	-	Н	*	OK or ERR	ERR	
INPUT 1 Progressive : 2D	R	A	\rightarrow	P	-	-	⊢	0	OK or ERR	ERR	
INPUT 1 Progressive : 3D	R	A		P	Ψ.		-	1	OK or ERR	ERR	
INPUT 1 Progressive : Fim Mode	R	A		P	. Τ.		-	2	OK or ERR	ERR	
INPUT 1 Signal Type : Auto	1	Α	S	ï	-	-	H	0	OK or ERR	ERR	
INPUT 1 Signal Type : RGB	i	Α	S	il		-	=	1	OK or ERR	ERR	
INPUT 1 Signal Type : Component	i	Α	S	il		-	=	2	OK or ERR	ERR	
INPUT 2 Picture Mode : Standard	R	В	\rightarrow	s	-	-	1	0	OK or ERR	ERR	
INPUT 2 Picture Mode : Presentation	R	Б.		s	Ψ.		1	1	OK or ERR	ERR	
INPUT 2 Picture Mode : Movie	R	В.		s	Ψ.		1	2	OK or ERR	ERR	
INPUT 2 Picture Mode : Game	R	В.		s	Ξ.	7	1	3	OK or ERR	ERR	
INPUT 2 Picture Mode : sRGB	R	В		s	Ξ.	7	ï	4	OK or ERR	ERR	
INPUT 2 Contrast (-30 - +30)	R	В	Р	Ì	Ī	*	*	*	OK or ERR	ERR	
INPUT 2 Bright (-30 - +30)	R	В		R		*	*	*	OK or ERR	ERR	
INPUT 2 Color (- 30 - + 30)	R	В	С	0		*	*	*	OK or ERR	ERR	
INPUT 2 Tint (- 30 - +30)	R	В	Т	T	_	*	*	*	OK or ERR	ERR	
INPUT 2 Red (-30 - +30)	R	В	R	D	_	*	*	*	OK or ERR	ERR	
INPUT 2 Blue (- 30 - + 30)	R	В	В	Е	_	*	*	*	OK or ERR	ERR	
INPUT 2 Sharp (-30 - +30)	R	В	S	Н	_	*	*	*	OK or ERR	ERR	
INPUT 2 CLR Temp *2	R	В	C	Т	_	*	*	*	OK or ERR	ERR	
INPUT 2 Bright Boost (0 – 2)	R	В	W	Е	_	_	_	*	OK or ERR	ERR	
INPUT 2 Progressive : 2D	R	В		Р	. . .			0	OK or ERR	ERR	
INPUT 2 Progressive : 3D	R	В		P	. . .	Ξ.		1	OK or ERR	ERR	
INPUT 2 Progressive : Flm Mode	R	В	_	P	_	_	_	2	OK or ERR	ERR	
INPUT 2 Signal Type : Auto	.!	В	S	Ш	. . .			0	OK or ERR	ERR	
INPUT 2 Signal Type : RGB	.1		S	Ц	Ψ.			1	OK or ERR	ERR	
INPUT 2 Signal Type : Component	1	В	S	1	-	-	-	2	OK or ERR	ERR	
INPUT 3 Picture Mode : Standard	V	Α		S	÷.		1	0	OK or ERR	ERR	
INPUT 3 Picture Mode : Presentation	V	Α		S	÷.		1	1	OK or ERR	ERR	
INPUT 3 Picture Mode : Movie	۷	Α		S	÷.	Ξ.	1	2	OK or ERR	ERR	
INPUT 3 Picture Mode : Game	٠.	Α		S	-	-	1	3	OK or ERR	ERR	
INPUT 3 Contrast (- 30 - + 30)	۷	Α	Р	1	-	_	Î	Î	OK or ERR	ERR	
INPUT 3 Bright (-30 - +30)	٧		В		-	^	Ĥ	_	OK or ERR	ERR	
INPUT 3 Color (- 30 - +30)	٧	Α		0	-	*	-		OK or ERR	ERR	
INPUT 3 Tint (- 30 - + 30)	٧	Α	T	1	-	^	Ĥ	_	OK or ERR	ERR	
INPUT 3 Sharp (-30 - +30)	٧	A		H	-	*	-		OK or ERR OK or ERR	ERR ERR	
INPUT 3 CLR Temp *2	V		C W	Ţ	-	_	Ë		OK OF ERR	ERR	
INPUT 3 Bright Boost (0 – 2) INPUT 3 Progressive : 2D	V	A		E P	-	-	-	0	OK OF ERR	ERR	
INPUT 3 Progressive : 2D	.v	A		P.	Ξ.			1	OK or ERR	ERR	
INPUT 3 Progressive : 3D INPUT 3 Progressive : Film Mode	.v	A		P				2	OK or ERR	ERR	
INPUT 3 Progressive : Fill I Mode INPUT 4 Picture Mode : Standard	V	В	_	S	-	-	1	0	OK OF ERR	ERR	
INPUT 4 Picture Mode : Standard INPUT 4 Picture Mode : Presentation	V	В		S			1	1	OK or ERR	ERR	
INPUT 4 Picture Mode : Presentation	.v			S	Ψ.	-	1	2	OK or ERR	ERR	
INPUT 4 Picture Mode : Movie	ľ			S.	Ψ.	-	.¦ 1	3	OK or ERR	ERR	
INPUT 4 Contrast (-30 - +30)	V	В	_	1	-	*	*	*	OK or ERR	ERR	
INPUT 4 Bright (-30 - +30)	V		В		-	*	*	*	OK or ERR	ERR	
INPUT 4 Color (- 30 - +30)	٠.	В			-	*	*	*	OK or ERR	ERR	
INPUT 4 Tint (-30 - +30)	V		T	H	-	*	*	*	OK or ERR	ERR	
IN 51 T IN (-00 T 30)	L V	ט	11	-1	-		4	Ļ	ON OF LITT	Lini	

									RETURN			
CONTROL CONTENTS	CO	IMC	MAN	ID	PAI	RAI	MET	ΓER	Power ON	Standby mode (or 40-second startup time)		
INPUT 4 Sharp (-30 - +30)	٧		S			*	*	*	OK or ERR	ERR		
INPUT 4 CLR Temp *2		В			_	*	*	*	OK or ERR	ERR		
INPUT 4 Bright Boost (0 – 2)	٧		W		_	_	_	*	OK or ERR	ERR		
INPUT 4 Progressive : 2D	٧		1		. .			0	OK or ERR	ERR		
INPUT 4 Progressive : 3D	٧	В		Р	. .			1	OK or ERR	ERR		
INPUT 4 Progressive : Film Mode	٧	В	I	Р	_	_	_	2	OK or ERR	ERR		
Clock (-150 - +150)	1	N		L	*	*	*	*	OK or ERR	ERR		
Phase (-30 - +30)	1	N		Н	_	*	*	*	OK or ERR	ERR		
H-Position (-150 - +150)	1	_	Н		*	*	*	*	OK or ERR	ERR		
V-Position (-60-+60)	1	Α		Р	_	*	*	*	OK or ERR	ERR		
Fine Sync Adjustment Reset	1	Α	R	-	_	_	_	1	OK or ERR	ERR		
Auto Sync : Off	Α	Α		J	. . .			0	OK or ERR	ERR		
Auto Sync : On	Α	Α	D	J	_	_	_	1	OK or ERR	ERR		
Internal Speaker : Off	Α	S	Р	K		ļ	ļ.,	0	OK or ERR	ERR		
Internal Speaker : On	Α	S		K	_	_	_	1	OK or ERR	ERR		
Image Shift	L	N	D	S	_	*	*	*	OK or ERR	ERR		
(-96-+96 (EIP-2500) / -75-+75 (EIP-200))												
OSD Display : Off		М			[]	ļ	ļ	0	OK or ERR	ERR		
OSD Display : On	1	М	D	1	_	_	_	1	OK or ERR	ERR		
Video System Selection : AUTO	М	Ε	S	Υ		ļ	l	1	OK or ERR	ERR		
Video System Selection : PAL	М	Е	S	Υ	_	l. –]_	2	OK or ERR	ERR		
Video System Selection : SECAM	M	Ε	S	Υ	_	_		3	OK or ERR	ERR		
Video System Selection : NTSC4.43	М	Е	S	Υ	_]_	4	OK or ERR	ERR		
Video System Selection : NTSC3.58	M	E	S	Υ	_	_]_	5	OK or ERR	ERR		
Video System Selection : PAL_M	M	Ε	S	Υ	_	_]_	6	OK or ERR	ERR		
Video System Selection : PAL_N	M	Ε	S	Υ	_	_]_	7	OK or ERR	ERR		
Video System Selection : PAL-60	M	Ε	S	Υ	_	_	1	8	OK or ERR	ERR		
Background Selection : Logo	Ι	М		G	_	_		1	OK or ERR	ERR		
Background Selection : Blue	Ϊ	М	В	G	_	_	1	3	OK or ERR	ERR		
Background Selection : None	Ï	М	В	G	_	_]_	4	OK or ERR	ERR		
Lamp Setting : Bright	T	Н	M		_	_	_	0	OK or ERR	ERR		
Lamp Setting : Eco + Quiet	T	Н	M		_	_]_	1	OK or ERR	ERR		
Auto Search : Off	Τ	N			1	_	_	0	OK or ERR	ERR		
Auto Search : On	Ï	N	S	Ε	_	_	-	1	OK or ERR	ERR		
Auto Power Off : Off	Α	Р	0	W	1	_	_	0	OK or ERR	ERR		
Auto Power Off : On	Α	Р		W	_	_	_	1	OK or ERR	ERR		
Auto Keystone : Off (EIP-2500 only)	Α	Т	K		_	_	Ī-	0	OK or ERR	ERR		
Auto Keystone : On (EIP-2500 only)	A	Ť	K	S	_	_]_	1	OK or ERR	ERR		
PRJ Mode : Reverse Off	Τ	М	R	Ε		_	I_	0	OK or ERR	ERR		
PRJ Mode : Reverse On	Ï	M		E		Ĺ.	Ľ	1	OK or ERR	ERR		
PRJ Mode : Invert Off	Ţ	М		N	. .	_	[<u> </u>	0	OK or ERR	ERR		
PRJ Mode : Invert On	ï	M	Ϊ	N		Ĺ	Ľ	1	OK or ERR	ERR		
Language Selection : ENGLISH	М	Ε	L	Α		-	[_	1	OK or ERR	ERR		
Language Selection : DEUTSCH	M	E	L	Α		[_]_	2	OK or ERR	ERR		
Language Selection : ESPAÑOL	M	E	L	Α		[_]_	3	OK or ERR	ERR		
Language Selection : NEDERLANDS	M	Е	L	Α		Ĺ]_	4	OK or ERR	ERR		
Language Selection : FRANÇAIS	М	Е	L	Α		L-]_	5	OK or ERR	ERR		
Language Selection : ITALIANO	M	Ε	L	Α		_]_	6	OK or ERR	ERR		
Language Selection : SVENSKA	M	Ε	L	Α		_]_	7	OK or ERR	ERR		
Language Selection : 日本語	M	E	L	Α		_]_	8	OK or ERR	ERR		
Language Selection : PORTUGUÊS	M	E	Ľ	Α		_	1	9	OK or ERR	ERR		
Language Selection: 汉语	M	E	Ľ	Α		_	1	0	OK or ERR	ERR		
Language Selection : 한국어	M	E	Ľ	Α		_	1	1	OK or ERR	ERR		
Setup Guide : Off	S	Ε	G	U		_	_	0	OK or ERR	ERR		
Setup Guide : On	S	E	G	U		-1	1	1	OK or ERR	ERR		
System Sound : Off	S	S	N	D	Ī	Ē	Ī	0	OK or ERR	ERR		
System Sound : On	S	S	N	D		٠ <u>٠</u>	1Ξ	1	OK or ERR	ERR		
RGB Horizontal Frequency Check	Т	F	R	Q	Ī	Ī	Ī	1	x10 ⁻¹ kHz (***.* or ERR)	ERR		
RGB Vertical Frequency Check	Т	F	R		Ť	Ē	Ī	2	Hz (***.* or ERR)	ERR		
Fan Mode : Normal	Н	L	M			Ē	Ē	0	OK or ERR	ERR		
	Н				· = ·	ŀΞ	17	1	OK or ERR	ERR		

Computer Compatibility Chart

Computer

 Multiple signal support Horizontal Frequency: 15-70 kHz, Vertical Frequency: 45-85 Hz, Pixel Clock: 12-108 MHz

Sync signal:Compatible with TTL level

• Compatible with sync on green signal

 Compatible with the signals below in intelligent compression
 EIP-2500: SXGA, SXGA+
 EIP-200: XGA, SXGA, SXGA+

 Intelligent Compression and Expansion System resizing technology

The following is a list of modes that conform to VESA. However, this projector supports other signals that are not VESA standards.

PC/MAC		and the s	Horizontal Frequency	Vertical Frequency	VESA Standard	Dis	olay
PC/IVIAC	H	esolution	(kHz)	(Hz)	VESA Standard	EIP-2500	EIP-200
			27.0	60			
		640 × 350	31.5	70			
			37.5	85	V		
			27.0	60			
		640 × 400	31.5	70			
			37.9	85	V		
		720 × 350	27.0	60			
		720 × 000	31.5	70			
	VGA		27.0	60			Upscale
		720 × 400	31.5	70			
			37.9	85	V		
		640 × 480	26.2	50		Upscale	
			31.5	60	V	Upscale	
			34.7	70			
PC SV			37.9	72	V		
			37.5	75	· ·		
			43.3	85	V		
		800 × 600	31.4	50			True
			35.1	56	V		
			37.9	60	V		
	SVGA		46.6	70			
			48.1	72	V		
			46.9	75	V		
			53.7	85	· ·		
			40.3	50			
			48.4	60	V]	ĺ
	XGA	1,024 × 768	56.5	70	· ·	True	
			60.0	75	V		
			68.7	85	· ·		Intelligent
			55.0	60			Compressio
	SXGA	1,152 × 864	66.2	70		Intelligent	
3	1		67.5	75	V	Compression	
	L	1,280 × 1,024	64.0	60	V	22	
		$1,400 \times 1,050$	64.0	60			
MAC 13"	VGA	640 × 480	34.9	67			Upscale
MAC 16"	SVGA	800 × 600	37.8	60		Upscale	True
		832 × 624	49.7	75			Intelligent
MAC 19"	XGA	1,024 × 768	60.2	75		True	Compression
MAC 21"	SXGA	1,152 × 870	68.7	75	I	Intelligent Compression	Compicasion

- When this projector receives 640 × 350 VESA format VGA signals, "640 × 400" appears on the screen.
- Optimum image quality will be achieved by matching your computer's output resolution to the projector's native resolution. (1024 x 768 for the EIP-2500 model OR 800 x 600 for the EIP-200 model).

DTV

Signal	Horizontal Frequency (kHz)	Vertical Frequency (Hz)
480I	15.7	60
480P	31.5	60
540P	33.8	60
576I	15.6	50
576P	31.3	50
720P	45.0	60
1035I	28.1	50
1035I	33.8	60
1080I	28.1	50
aded From proje	ctor-manual com FIK	I Manual ⁶⁰

Troubleshooting

Problem	Check	Page
	Projector power cord is not plugged into the wall outlet.	26
	Power to the external connected devices is off.	_
	The selected input mode is wrong.	30
	Cables incorrectly connected to the projector.	23-26
	Remote control battery has run out.	14
No picture and no sound or projector does not	External output has not been set when connecting notebook computer.	23
start.	The lamp unit cover is not installed correctly.	51, 52
	Cables incorrectly connected to the projector.	23-26
	"Bright" is set to minimum position.	40
Sound is heard but no icture appears (or picture is dark).	Depending on the computer you are using, an image may not be projected unless the signal output setting of the computer is switched to the external output. Refer to the owner's manual of the computer for how to switch its signal output settings.	_
	Image adjustments are incorrectly set. Make adjustments of "Color" and "Tint" in "Picture Mode" and lower the "Bright Boost" value.	40
Color is faded or poor.	(Video Input only) • Video input system is incorrectly set.	46
	Adjust the focus.	28
	The projection distance exceeds the focus range.	20
	(Computer Input only)	
	Perform "Fine Sync" Adjustments ("Clock" Adjustment)	46
	Perform "Fine Sync" Adjustments ("Phase" Adjustment)	46
Picture is blurred; noise appears.	Noise may appear depending on the computer.	_
	Cables incorrectly connected to the projector.	23-26
	Volume is set to minimum. When the projector is connected to an external device and the volume is set to minimum, the sound is not output even if you turn up the volume of the external device.	30
Picture appears but no sound is heard.	"Speaker" is set to "Off".	43
An unusual sound is occasionally heard from the cabinet.	If the picture is normal, the sound is due to cabinet shrinkage caused by room temperature changes. This will not affect operation or performance.	-
Maintenance indicator on the projector illuminates or blinks in red.	See "Maintenance Indicators".	49
The projector cannot be turned on or put into the standby mode using the STANDBY-ON button on the projector.	The keylock is set. If the keylock is set to "ON", all the buttons are locked.	45

Troubleshooting (Continued)

Problem	Check	Page
Picture is green on INPUT 1 (COMPONENT)/INPUT 2 (COMPONENT).	 Change the input signal type setting. When you cannot select an input signal type, select "Color is faded or poor" in the "Help" menu, after selecting an item other than 	46 39, 46
Picture is pink (no green) on INPUT 1 (RGB)/INPUT 2 (RGB).	"sRGB" in "Picture Mode", and then select an input signal type.	
Picture is too bright and whitish.	Image adjustments are incorrectly set.	40
The cooling fan becomes noisy.	 When temperature inside the projector increases, the cooling fan runs faster. 	_
The lamp does not light up even after the projector turns on.	 The lamp indicator is illuminating in red. Replace the lamp. 	48, 51
The lamp suddenly turns off during projection.		
The image sometimes flickers.	 Cables incorrectly connected to the projector or the connected equipment works improperly. 	23–26
	 Select "Vertical stripes or flickering image appear" in the "Help" menu and make the necessary adjustments. 	46
	 If this happens frequently, replace the lamp. 	51
The lamp needs much time to turn on.	 The lamp will eventually need to be changed. While the remaining lamp life draws to a close, replace the lamp. 	51
Picture is dark.		

This unit is equipped with a microprocessor. Its performance could be adversely affected by incorrect operation or interference. If this should happen, unplug the Unit and plug it in again after more than 5 minutes.


Specifications


```
Product type Projector
                   Model EIP-2500/EIP-200
           Video system NTSC3.58/NTSC4.43/PAL/PAL-M/PAL-N/PAL-60/SECAM/DTV480I/DTV480P/
                           DTV540P/DTV576I/DTV576P/DTV720P/DTV1035I/DTV1080I/DTV1080I-50
                           Single Chip Digital Micromirror Device™ (DMD™) by Texas Instruments
         Display method
             DMD panel Panel size: [EIP-2500] 0.55" (14 mm), 1chip XGA DMD
                                       [EIP-200] 0.55" (14 mm), 1chip SVGA DMD
                           No. of dots: [EIP-2500] 786,432 dots (1,024 [H] × 768 [V])
                                        [EIP-200] 480,000 dots (800 [H] × 600 [V])
                    Lens 1-1.15 \times \text{zoom lens}. F2.4-2.6. f = 19.0-21.9 mm
         Projection lamp 275 W DC lamp
Component input signal 15-pin mini D-sub connector
             (INPUT1/2) Y: 1.0 Vp-p, sync negative, 75 \Omega terminated
                           P<sub>B</sub>: 0.7 Vp-p, 75 Ω terminated
                           P_R: 0.7 Vp-p, 75 \Omega terminated
    Horizontal resolution [EIP-2500] 600 TV lines (DTV720P)
                           [EIP-200] 520 TV lines (DTV720P)
   Computer RGB input
                           15-pin mini D-sub connector
      (INPUT 1/2)/output
                           RGB separate/sync on green type analog input: 0–0.7 Vp-p, positive, 75 \Omega terminated
                           HORIZONTAL SYNC. SIGNAL: TTL level (positive/negative)
       (OUTPUT) signal
                           VERTICAL SYNC. SIGNAL: Same as above
     S-video input signal 4-pin mini DIN connector
               (INPUT 3)
                           Y (luminance signal): 1.0 Vp-p, sync negative, 75 \Omega terminated
                           C (chrominance signal): Burst 0.286 Vp-p, 75 \Omega terminated
       Video input signal RCA connector: VIDEO, composite video, 1.0 Vp-p, sync negative, 75 Ω
               (INPUT 4) terminated
      Vertical frequency 45-85 Hz
   Horizontal frequency
                           15-70 kHz
              Pixel clock 12-108 MHz
      RS-232C terminal 9-pin mini DIN connector
       Audio input signal Ø3.5 mm minijack or RCA terminal: 0.5 Vrms, more than 22 kΩ (stereo)
     Audio output signal ø3.5 mm minijack: 0.5 Vrms, less than 2.2 kΩ
  (AUDIO OUTPUT 1-4)
        Speaker system 4 \text{ cm} \times 2.85 \text{ cm oval} \times 1
           Rated voltage AC 100-240 V
            Input current 3.6 A
        Rated frequency 50/60 Hz
     Power consumption 350 W (Lamp Setting "Bright")/
                           305 W (Lamp Setting "Eco + Quiet") with AC 100 V
                           330 W (Lamp Setting "Bright")/
                           285 W (Lamp Setting "Eco + Quiet") with AC 240 V
Power consumption (standby) 4 W (AC 100 V) - 5 W (AC 240 V)
        Heat dissipation 1,315 BTU/hour (Lamp Setting "Bright")/
1,145 BTU/hour (Lamp Setting "Eco + Quiet") with AC 100 V
1,240 BTU/hour (Lamp Setting "Bright")/
1,070 BTU/hour (Lamp Setting "Eco + Quiet") with AC 240 V
  Operating temperature 41°F to 95°F (+5°C to +35°C)
                           -4°F to 140°F (-20°C to +60°C)
    Storage temperature
                 Cabinet Plastic
    I/R carrier frequency
                           38 kHz
   Dimensions (approx.)
                           12^{13}/32'' \times 4^{19}/64'' \times 11^{11}/32'' (315 (W) × 109 (H) × 280 (D) mm) (main body only)
                           12^{13}/_{32}" \times 4^{47}/_{64}" \times 11^{37}/_{64}" (315 (W) \times 120 (H) \times 294 (D) mm) (including adjust-
                           ment foot and projecting parts)
        Weight (approx.)
                           8.6 lbs. (3.9 kg)
                           Remote control, Power cord for U.S. and Canada, etc., Power cord for Europe,
     Replacement parts
                           except U.K., RGB cable, 3 RCA to 15-pin D-sub cable, DIN-D-sub RS-232C
                           adaptor, Quick Guide, Owner's manual (Printed and CD-ROM)
```


As a part of policy of continuous improvement, EIKI reserves the right to make design and specification changes for product improvement without prior notice. The performance specification figures indicated are nominal values of production units. There may be some deviations from these values in individual units.

Dimensions

Units: inches (mm)







Downloaded From projector-manual.com EIKI Manuals

Index

3 RCA to 15-pin D-sub cable	24 Lamp
AC socket	
	1 0
Accessories	
Adjustment buttons	
Adjust horizontal noise	
Adjust vertical noise	46 Lens Cap11
Aspect ratio	32
AUDIO INPUT terminal	25 MENU/HELP button
AUDIO OUTPUT terminal	21
Auto Keystone Correction	
Auto Power Off	40
Auto Fower Off	ON DUILOIT27
	Optional accessory10
Auto Sync	OSD Display42
(Auto Sync adjustment) 34, 36, 43,	OUTPUT (INPUT1, 2) terminal
AUTO SYNC button	34
AV MUTE button	30 PDF9
	Phase46
Background	
Blue	40 Picture Mode
BORDER 32,	PICTURE MODE button
BREAK TIMER button	
Bright	40 Fower Cord20
Bright Boost	40 1110 - AD3
Bright Boost	FR3 Wode 19, 42
Clock	46 Progressive40
CLR Temp (Color Temperature)	40
Color	11-0 batteries
	Bear adjustment 1001 29
Contrast	⁴⁰ Red
DIN-D-sub RS-232C adaptor	Remote control
DIN-D-Sub H3-2320 adaptor	Remote control sensor15
ENTER button	
Exhaust vent	
Extradist vont	
Fan Mode	RESIZE button
Fine Sync	AE TURN DUTTON37
Focus ring	20 NGB Cable23
FREEZE button	
Front adjustment foot	
H-Pos	Screen Size and Projection Distance
HEIGHT ADJUST lever	
	Sharn
Help	⁴⁶ Speaker43
Image shift	41 STANDBY button
	TI OTANDOV ONLI II
INPUT 1 terminal	OTDETOIL 00 00
INPUT 1 – 4 modes	
INPUT 2 terminal 23, 24,	O
INPUT 3 terminal	24 System Lock44
INPUT 4 terminal	25 System Sound43
INPUT buttons	30 —
Intake vent	1emperature warning indicator48
	47 Tint40
Kensington Security	
Standard connector	12 Video System36
Keycode	
Keylock	
KEYSTONE button	40
Koyotona Correction 04	41 _{01s} Zoom ring28
Downlbaystopeoficpffeetor-manual:com EIKI Man	nuals 20011 11119



U.S.A.

EIKI International, Inc. 30251 Esperanza Rancho Santa Margarita CA 92688-2132 U.S.A.

Tel: 800-242-3454 (949)-457-0200 Fax: 800-457-3454 (949)-457-7878

E-Mail: usa@eiki.com

Deutschland & Österreich

EIKI Deutschland GmbH Am Frauwald 12 65510 Idstein Deutschland Tel::06126-9371-0

Fax: 06126-9371-14 E-Mail: info@eiki.de

Canada

EIKI CANADA - Eiki International, Inc. P.O. Box 156, 310 First St. - Unit 2, Midland, ON, L4R 4K8, Canada Tel : 800-563-3454 (705)-527-4084 Fax: 800-567-4069 (705)-527-4087

E-Mail: canada@eiki.com

Eastern Europe

EIKI CZECH spol. s.r.o. Umělecká 15 170 00 Praha 7 Czech Republic Tel: +42 02 20570024

+42 02 20570024 +42 02 20571413 Fax: +42 02 20571411

E-Mail: easterneurope@eiki.de

Japan & Worldwide

EIKI Industrial Company Limited. 4-12 Banzai-Cho, Kita-Ku, Osaka, 530-0028 Japan

Tel: +81-6-6311-9479 Fax: +81-6-6311-8486

WorldWide Website http://www.eiki.com